

206

A DRIVER TO
INTERFACE THE DGDAC SUBSYSTEM
AND THE GOSEX SYSTEM

A SOFTWARE DRIVER TO
INTERFACE THE DGDAC SUBSYSTEM
AND THE GOSEX SYSTEM

By
DAVID ERNEST SIMONS, B.A.Sc.

A Project
Submitted to the School of Graduate Studies
in Partial Fulfilment of the Requirements
for the Degree
Master of Science

McMaster University

September 1977

MASTER OF SCIENCE (1977)
(Computation)

McMaster University
Hamilton, Ontario

TITLE: A Software Driver to Interface the DGDAC
 Subsystem and the GOSEX System

AUTHOR: David Ernest Simmons, B.A.Sc. (Queen's University)

SUPERVISOR: Dr. P.C. Chakravarti, Dr. J.D. Wright
 (Chemical Engineering)

NUMBER OF PAGES: vi, 99

ABSTRACT:

A Software Driver has been written to interface the DG/DAC (Data General's Data Acquisition and Control) Subsystem and the GOSEX (Generalized Operating System Executive) System. The interface handles the input-output requirements of GOSEX and was written to allow for dual processing on Data General Nova Computers.

The code was written to appear transparent to the user as well as to add additional features to the GOSEX system.

A discussion of current Industrial Data Acquisition and Control systems is included with recommendations on time and cost saving strategies.

ACKNOWLEDGEMENT

The author wishes to express his gratitude to those who have assisted him in the successful completion of this project. In particular, he wishes to thank:

Dr. J.D. Wright for his helpful guidance throughout this study.

Dr. P.C. Chakravarti for his advice and for the time spent discussing problems associated with this project.

My wife Audrey, for her perseverance.

Mrs. Hilary Karik, for the speedy typing of this project.

McMaster University for assistanceships and scholarships.

TABLE OF CONTENTS

	Page
1- INTRODUCTION	1
2- CURRENT PROCESS CONTROL SOFTWARE SYSTEMS	4
2.1 Survey of Process Control Problems	5
2.2 Current Software Systems	7
3- DESCRIPTION OF THE SYSTEM	10
3.1 The Computer System	11
3.2 The GOSEX Executive System	18
3.3 The DGDAC subsystem	21
4- DESCRIPTION OF THE INTERFACE SOFTWARE	25
4.1 The DGDAC-GOSEX Interface	26
4.2 Description of the Code	30
5- CONCLUSIONS	33
6- BIBLIOGRAPHY	99

INDEX OF FIGURES

	Page
1- Layout of the Hardware in the Chemical Engineering Control Laboratory	35
2- DGDAC Configuration	36
3- Flow of GOSEX Pertaining to the Interface with the I/O Subsystem	37
4- Changes and Additions to PREP	39
5- Changes and Additions to PTAPE	59
6- Flow of DCLAR	68
7- MTPLX - Output Handler	69
8- POLLR - Input Handler	71
9- Code of MTPLX Routine	73
10- Additions to OPCOM Messages	94

1-

INTRODUCTION

In the last five years a dramatic shift has occurred in the cost factors of minicomputer systems. With the increased efficiency of producing hardware and with greater competition among vendors the cost of minicomputers has substantially decreased while the cost of producing software has grown almost inversely proportionally to the fall of hardware prices.

This development of inexpensive minicomputers has lead to the widening interest in Digital Process Control Systems. Digital Control Computers are being used to monitor the operation of plants, log relevant process variable data, indicate alarm conditions, control processes, and to generally optimize the operation of a process.

The principal feature of a process control system, which make it different from an interactive time-sharing system, is the handling of the input and output signals and its process interrupt system.

Within this project, it will be shown how a minicomputer is used to handle the input-output (I/O) operation of a process control system and how the interrupt structure is used in conjunction with the workings of the system. In particular the I/O and interrupt handling structure of the GOSEX^{5*} system are examined

* This number refers to references listed in the Bibliography.

with the necessary changes required for the addition of the DG/DAC³ subsystem.

One of the key developments in Process Control Systems recently has been the writing of executive packages. These packages free the user from the great deal of programming which is necessary before the operator-system communications, in an experiment using digital process control, can be carried out. The user is merely responsible for certain sections of the code to describe the unique parameters of the experiment.

At McMaster University, the Chemical Engineering Department has developed a generalized operating system executive (GOSEX) which is used for on-line data acquisition and control of chemical processes. The package contains a large number of utility programs, executive functions and executive tasks. It allows the user full interactive control over data logging, control software, on-line parameter adjustments, and process variable alarming with minimal programming additions from the user. The GOSEX system has been in use in the Chemical Engineering Control Laboratory since 1974 and is also in industrial use for process research at the Bruce Heavy Water Plant of Ontario Hydro at Tiverton, Ontario.

Recently additional I/O devices have been required and the I/O hardware (which is six years old) has proven inadequate for current modes of operation. The old hardware does not provide enough I/O channels for future use and only allows porting to one of the two computers in the system.

Consequently, the decision was made to order a completely new analog subsystem. The DG/DAC subsystem allows for a dual processing system and flexible I/O applications. It appears to the process system as one interrupting device and has its own programming requirements.

Because of this change to the I/O subsystem in the Chemical Engineering Control Laboratory it was required to change that part of the code in GOSEX which deals with the I/O devices. The DG/DAC programming requirements, the addition of new I/O drivers, and a new interrupt scheme was developed for the change. The change appears transparent to the user except for the requirement of an addition digital to the analog table of values. The system operates in essentially the same way as the original version.

In addition, a discussion of the current status of process control computers is included with some observations from the author on time and cost saving strategies.

2- CURRENT PROCESS CONTROL SOFTWARE SYSTEMS

The large and increasing numbers of firms which are involved in the design and implementation of the hardware and software of Process Control Systems have lead to many distinct methods of handling the problem. The following is a review of some of the techniques which are used and a discussion of problems faced by the users of these products.

2.1 Survey of Process Control Problems

Once a firm has shown justification of a process control system the development of the system can take many paths. A firm without the resources to handle software development or hardware specifications may hire a consulting firm to provide a Turn-Key system. This is usually the most expensive method and can result in the firm being dependent on the consultant for any modifications once the contract requirements are met. The firm must also check the consultants work to see if the code and the resources were used efficiently, if the optimization schemes were properly utilized, if the program is easily expandable, and if all the system specifications were met.

In the author's own experience a Turn-Key system was delivered which failed all of the above criteria. The system, to monitor a gas transmission plant, was designed and written by inexperienced personnel and many years of problems were faced by the gas transmission company. Some other problems were not foreseen which caused many delays and significant expenditures. The CPU which was used was manufactured in Canada, but since the consultant was located in the United States the gas company paid double duty on the unit. Additional hardware ordered from the consultant was charged at significantly higher prices and training for new operating personnel was prohibitively expensive. A simple disc cartridge was quoted at four hundred dollars (\$400.00) by the consultant while the same unit was purchased from the original

equipment manufacturer for eighty-five dollars (\$85.00). The system proved so inflexible that finally a programmer was hired to completely redesign and rewrite the software.

Generally, the best method to develop a Process Control System is to purchase a general package and develop the specific requirements in-house. The firm should have a programmer who is able to develop systems from such a base and be available to maintain these systems. Process Control projects normally change in scope between the design and end-product stages and the firm needs the independence that is gained when having its own employees complete the task.

In the past, when designing process control systems, the system was usually designed from the bottom up. Often the design was started by considering the control loops and the memory cycle speed of the computer as the basic design criterion⁶. The design would work up finally adding the operator interface at the top level.

The principles of software engineering indicate that computer systems should be designed from the top down by successive refinements. We should start by considering what results we want and then design from there. It is essential that the computer be fast enough to do the job but this should not be a base for the design but something checked on after the system's completion. The last decision to be made in the design should be which mini-computer should be included.

2.2 Current Software Systems

The varying applications of process control have led to a wide variety of operating system executives. Some systems maintain a large database and mostly involve I/O scheduling. Others are compute bound and rely on the optimization routines of the computer. Still others exercise little or no control over the process and are merely report producing monitoring systems.

The following paragraphs summarize the packages currently offered by some companies.

1) Fisher Controls, Marshalltown, Iowa.

Fisher has developed its own Process Control language called PC² which is very similar to BASIC with some added I/O commands for real-time systems. The system is based on a 32K word processor which is expandable to 64K. The system is good for general use but interfacing to other hardware, except Fisher equipment, is difficult. The PC² compiler is hardwired which requires an extra 4K words of memory. The user cannot link his own assembler routines to the package which limits some applications.

2) Foxboro Company, Foxboro, Mass.

Foxboro has developed an integrated control system called INTERSPEC, which allows each Foxboro unit in the system to interact predictably well with every other Foxboro element. Their software incorporates a Fill-In-The-Forms⁷ method to allow the user to perform all the functions by merely answering questions about his application.

This approach results in considerable savings in software development costs but the programs tend to be large, and very general, and require substantial memory. It is also possible to require new applications which the "Fill-In-The-Blanks" method does not cover.

3) Taylor Instrument Company.

Taylor Instruments has developed an interactive Process Control language called POL*3 (Process Orientated Language-3)⁸. POL*3 allows the user to avoid the compiling stage and permits the user to execute tasks while the computer is on-line. Thus the user can work with the I/O and change the process requirements while on-line. POL*3 is an interpreter which causes the users programs to access subroutines which handle the requests.

4) The Purdue Fortran

The Fortran Committee of the Purdue Workshop on Standardization of Industrial Programming Languages attempted, in 1972, to unify the different process control extensions to Fortran by developing Purdue Fortran¹⁰. This has since become an industrial standard. The language takes ANSI Fortran as a base and adds a set of standard procedures for process control. Purdue Fortran has eighteen procedures for starting tasks, process I/O bit string manipulations, and time and date information.

5) Digimatics Ltd.

Digimatics has developed a high level process control language called ABACUS⁹ which allows the user to describe his

system by means of block schematic control diagrams similar to conventional analogue control and logic signals. The information about the block schematic is entered directly to the computer. The required software, being closely related to block diagrams, is one the user can easily picture and work with.

Other systems which may be of interest to the reader include those supplied by Bailey Meter, Bristol, Honeywell, and Metromation. Each of these has its own special features but all of them are inefficient and inflexible for special purpose applications.

Most firms offer the ability to have a backup computer for important processes. This requires a dual processing system with both computers sharing the same disc. This ensures that when the on-line computer fails no data is lost and that the control process can immediately continue. The back-up computer can be used for other purposes while it awaits for the main computer to fail.

3- DESCRIPTION OF THE SYSTEM

The three basic components of the system which were changed will be described on the following pages. They are the computer system, the GOSEX software package, and the programming requirements of the DG/DAC subsystem.

3.1 The Computer System

Figure 1 shows the layout of the hardware in the Chemical Engineering Control Laboratory. The computers were manufactured by Data General Corporation, have a 16 bit word length, and have a memory size of 32,768 words.

The instruction set of the Nova computers contain instructions that perform fixed point arithmetic and logical operations between accumulators, transfer of operands between accumulators and main memory, transfer of program control, and I/O operations. The instruction set was designed to allow for many operations to be performed by one instruction, allowing complex routines to be written by a small number of instructions.

The computer operation is performed sequentially, executing the instructions of a stored program one by one. In small systems the computer proceeds without interruption, continuing until the solution is complete. In general this mode of operation results in inefficient use of computer resources and does not allow for fast responses to process interrupts which are commonly required in process applications. The following are examples illustrating how interrupts can solve the above two problems.

Consider a case in which the control computer is monitoring the pressure of a gas at the discharge of a compressor station. If the pressure goes below a certain reading the compressor is to be turned on increasing the pressure in the gas transmission line. The compressor is to be turned on within five minutes after the

violation of limits occurs if sufficient pressure is to be maintained in the pipeline.

Using Murphy's Law^{*} it is quite probable that the computer would be initiating a lengthy optimization calculation, that requires ten minutes of computing, at the instant the violation occurs. Clearly, without the interrupt capability the computer could not respond to the process event in the required time.

The efficient use of computer resources may be illustrated by examining the operating speeds of the processor and the I/O units. The processor can execute over one million instructions per second compared with thirty characters per second for a typical output terminal. Thus if sequential execution were followed the processor would always be waiting for work while the terminal slowly operated. The interrupt feature allows many thousands of instructions to be executed while the I/O units are operating.

In the basic interrupt scheme there are six functions which must be carried out:

- 1) Detection of an interrupt
- 2) Indication of the source of the interrupt
- 3) Saving of information so the execution of the interrupted program can later be resumed
- 4) Transfer of control to the interrupt handling program
- 5) Execution of the interrupt handling program

* If anything can go wrong it will.

6) Return of control to the interrupted program

These functions could all be performed by the program if the programmer added sufficient code. This could be done by having the program periodically compare all input values to pre-set limits and have the program branch to code to service any limit violating conditions. This would require the programmer to time the execution of segments of code so that the program can transfer to the limit checking code at periodic time intervals. The routine would have to store the state of the program at every transfer thus increasing the number of instructions executed, and increasing execution time and storage requirements. Obviously, the hardware interrupt process is preferable for the majority of process control applications.

Advancing the concept of interrupts we find that it is advantageous to assign each possible interrupting device a level of priority. For example, an interrupt from an input device, indicating that digital data is to be read, should be ignored if the computer is presently handling an interrupt to an emergency condition in the process.

Three types of interrupts exist on the system:

1) System Interrupts.

These are generated by the computer system itself and is key to the functioning of the system. When the teletype has finished outputting a character and is ready for another a system interrupt is generated.

2) Timer Interrupts.

In our system the operator must initialize a user clock which indicates what action is to be done periodically by the program. An example is if an optimization calculation is to be done every ten minutes the timer interrupt would be set to ten minutes.

The user clock is essentially a subroutine which contains a counter. The system clock runs at 10 Hz and interrupts the program every one-tenth of a second. The interrupt forces the counter in the clock subroutine to increment and to be compared with a set value which was initialized when the user clock was set by the user. When the counter is equal to the set value a timer interrupt occurs.

3) Process Interrupts.

These interrupts originate from the process and either signal that some routine is to be executed by the computer or signal that a message indicating an alarm condition is to be generated. In the Chemical Engineering Control Laboratory system the user can execute a GOSEX function by typing CTRL E on the teletype, thus issuing a process interrupt.

In Data General systems¹¹ two levels of priorities are present. High priority interrupt devices are contained in the HINT dispatch table. Examples of these are the real time clock and the power fail/auto restart device. The lower priority devices are wired to a particular bit of the 16 bit priority mask and have entrees in the device interrupt vector table (ITBL). More than one

device can be wired to a particular bit. By changing the mask word upon interruptions the servicing program can inhibit specified levels of interrupts and thus establish a priority scheme. By use of the mask bits the user can guarantee that a servicing program will not be interrupted. The masking function only delays the recognition of an interrupt and thus the interrupt is not lost.

Figure 2 shows the system configuration in the Chemical Engineering Control Laboratory, including the two minicomputers, the DG/DAC unit, and the I/O devices. The dual processors share control of the DG/DAC subsystem, each having its own crate controller.

Details of each I/O module is given below:

- 1) 4290 General Purpose Input Module (to be used as a Contact Sense Device).

The Contact Sense device consists of a 16 bit data register which stores the state of sixteen independent lines. When a transition is detected in any of the lines the module initiates a program interrupt request. The program must then analyze the status of the data register to determine which of the lines changed state and caused the interrupt. The module can also be used to store the state of the sixteen independent lines only upon user request and without causing an interrupt.

- 2) 4291 TTL Input Module (Two modules in system).

The TTL input modules each contain a 16-bit data register which stores the state of sixteen independent TTL compatible input lines. The data register receives the digital data from

the input lines on command from the program or can be programmed to initiate an interrupt upon reception of data from one of the input lines.

3) 4297 Form C Relay Output Module

The relay module controls 17 independent form C reed relays. The module contains a 16-bit data register which controls the value of sixteen of the relays with the seventeenth relay (start pulse relay) being controlled by a module flag command (the S-function).

Physically the Form C relay is a mercury-wetted relay which is activated by a magnetic field. The mercury covers all contact surfaces and thus eliminates bounce when the contacts close.

4) 4299 TTL Output Module (Two modules in system)

The TTL output modules each control eighteen independent TTL compatible output lines. Sixteen of these lines are controlled by bits in a 16-bit data register while the other two are strobe lines which are controlled by module flag commands (the S, C, and IORST functions).

5) 4288 Series D/A Converters (Two converters in system)

The D/A converters provide analog voltage output on four program selectable output lines. The output voltage range is 0-10 volts and the resolution of the digital value to be converted is 12 bits. The digital to analog converter is used to control analog devices such as valves or setpoints.

6) A/D Cluster

The A/D cluster consists of an analog to digital input device plus two voltage multiplexors and one current multiplexor. The cluster is used to provide a digital representation of an analog signal. The three components of the cluster are:

a) 4280 A/D Converter.

The A/D converter operates under Data Channel Operation, that is, the address in core, where the converted digital data is to be stored, is given and all the converted data is stored there. This is opposed to individual digital values being stored by the program as in Programmed I/O Operation. The digital data has 12-bit resolution. The three multiplexors are differential multiplexors which requires two channels per analog signal. The major advantages of this are, first, the ability to handle low-level as well as high level signals, and second, the additional performance requirement of common mode rejection.

b) 4281 Voltage Multiplexors (two in cluster).

The input voltage range is 0 - 10 volts. The Voltage Multiplexors have programmable select gains with values of 1,2,4 and 8.

c) 4281C Current Multiplexors.

The current multiplexor inputs a signal of 10 - 50 ma to the A/D converter.

3.2 The GOSEX Executive System

The GOSEX package is a group of utilities and executive functions used as the base for real time process control applications. The user has to develop a minimal number of subroutines to make use of the executive package. The package is flexible and can be used for a variety of applications on any NOVA-line minicomputer operating under Data General's real time disk operating system (RDOS). The GOSEX package occupies approximately 4K words of central processor memory, leaving approximately 14K words for user programming in a 32K word machine.

The package consists of three distinct types of routines:

1) Utilities.

The utilities are routines which support the package functions. They are composed of twenty-eight core resident programs which are re-entrant to allow for their use in different interrupt levels. Under RDOS, the re-entrant subroutines are essentially read-only code and each reference to the routine creates a separate area for the data and intermediate results. A description of each utility is available.⁵

2) Executive Tasks.

The executive tasks are routines which initialize the system at run-time, check for alarm conditions, and control the transfer of data between the system and the plant. The main program, INTRP, allows initial operator-system communication, and handles operator interrupts. The routine named INITR allows the user to

output messages to the keyboard during alarm conditions. The interface handler is called !ITPLX. !ITPLX was rewritten as part of this project but its purpose remains unchanged. It initiates the input devices, handles the outputs when requested by the users clock, and handles the inputs when the input interrupts request service. Routines are also available to generate logged output, plots, profile output, and copy output.

3) Functions

The functions supply an individual task to the system and are executed by user request, upon the operator interrupt, given by CTRL E. The user can also supply special purpose functions which can be linked to the system. Examples of functions are STATS, which will print out the status of the run, and LOG, which will initiate a display of data on any of the output devices.

The requirements of the user are to supply a number of programs, tables, and constants which are used by the executive programs to uniquely describe the system. The constants are to be set in a routine called PTAPE which will supply GOSEX with the limiting values and the number of devices in the system. The user must supply routines to shut down the system, and to handle the calculations necessary in his application. Message files must be provided for the alarm conditions and tables must be set-up to hold the data for the I/O devices.

The executive function PREP is called at run-time to study the inputs given by the user and will generate diagnostics

upon the location of errors. The PREP routine was changed in this project to reflect the changes to the tables necessary for the enlarged I/O subsystem. A sample run of GOSEX is available.⁵

3.3 The DG/DAC Subsystem

The following is a review of the programming requirements of the DG/DAC subsystem. Each I/O device has its own programming requirements and handles the data in a unique way.

1) 4290 General Purpose Input Device (Contact Sense Device).

The Contact sense device is programmed in two separate steps, first, starting the device, and second, servicing it upon the change of one of its bits. To start the device the module first must be selected by indicating its slot address in the Specify Address and Context (DOA) statement. Then a start flag is given (S) which will start the device and enable the module interrupts.

To service the device, upon an interrupt, the individual bits of the data register must be compared with their previous values to locate which bit changed status. Once the bit is located a message is transmitted to the user disclosing the change and the contact sense device is again started.

2) 4291 TTL Input Module.

The TTL input device has to be initialized, serviced when ready, and started. The device is selected and started with a Specify Address and Context (DOAS) statement with the slot address in the appropriate bits. This enables the module interrupt and allows the device to interrupt the system when the input is present in the data register. When this occurs the data is read and placed in the table TTLI1 or TTLI2 in memory, depending on

which TTL input device handled the data.

3) 4297 Form C Relay Output Module.

Part of the requirements of the user is that he must set the frequency at which the system will output data, read the analog to digital and TTL input data. This is given by the constant SCAN in the users own program. From this sampling rate a user clock¹¹ is defined which will force an interrupt every sampling unit of time. When this timer interrupt occurs a branch to the output handler is made and the Form C relay is selected by a Specify Address and Context (DOA) statement with the slot address in the appropriate bits. The relay settings are then loaded into the data register by a Write Data (DOB) statement. The device is then started by a start flag (S) command which closes the Start Pulse relay for 50 ms and the data is subsequently output.

4) 4299 TTL Output Modules.

After the Form C relay data is output the TTL output modules are selected sequentially. The TTL output is loaded into the data register by a Write Data (DOB) statement and the device is then started by a start flag (S) command. The flag asserts the two external strobe lines and starts a 7 ms interval timer at which time the data is output.

5) 4288 Series D/A Converter

After the TTL data is output the D/A converters are selected sequentially. The eight D/A channels are selected in

sequence and the data and channel numbers are loaded into the data register by the Specify Conversion (DOB) instruction. The data is then converted to an analog signal and output. The procedure is then carried out for the other channels.

6) 4280 A/D Converter.

The A/D converter, current multiplexor, and the two voltage multiplexors are grouped together into a cluster. The gain values of the voltage multiplexors must be set, the ADC must be started, and the cluster serviced when ready. The gain values must be set prior to selecting the A/D converter. They are set by first selecting each voltage MPX by the Specify MUX Address (DOC) statement and then using the Specify Gain (DOB) instruction to output the gain value.

The cluster is then started by issuing the following instructions:

- a) Select the cluster with a Specify Address and Context (DOB) statement with the slot address in the appropriate bits.
- b) Indicate the number of conversions to be done by the Specify Conversion (DOB) statement. The following bits are to be set - initiate program interrupt on a data overrun error, command to propagate to the specified multiplexor when appropriate, trigger is set to DCHI (Data Channel Operation), automatic scanning of multiplexors, data channel mode, and the number of conversions is set to 3.
- c) Indicate the first multiplexor to be selected by the Specify

MUX address (DOC) with the number of multiplexors set to 3, and the first channel given in the Channel Select bits.

d) Indicate where in memory the converted data is to be stored by a Load Memory Address (DOC) instruction.

e) A start flag (S) is then given which will start the conversion.

When the conversion is finished and the digital data is stored in the table (DATUM) in memory, the program is interrupted to indicate that the conversion is complete. The validity of the data is then checked with a Read Module Status (DIA). Bit 3 will be one if there was a data overrun error. The request is then cleared with a clear flag (C) command.

4-

DESCRIPTION OF THE INTERFACE SOFTWARE

The following is a description of the software changes required for the new DG/DAC subsystem. A general discussion of the Code changes is first given followed by details of each required change. A written description, flow charts, and the actual code is included.

4.1 The DG/DAC - GOSEX Interface

Below is a discussion of the problems, decisions, and analysis which had to be done in implementing the new I/O subsystem within the existing operating system executive.

Initially it had to be determined which code of GOSEX was to be affected by the change. The entire MIPLX routine required change, PTAPE had to be expanded to allow for the additional I/O units, and PREP had to be changed to allow for the expansion.

Problems were encountered in the following areas:

- 1) Lack of documentation on the flow of the GOSEX routines. As is typical with assembler programs, individual sections of code were well documented but a systems flowchart, showing how the sections fit together, was lacking. This caused serious problems when designing the interface.
- 2) Lack of proper documentation on the programming of the DG/DAC subsystem. The programmer's reference manual was poorly written, lacked details, and had no examples. The programmers at Data General (Toronto) were most helpful in solving the "Fill-in-the Blanks" documentation.
- 3) The documentation on the Dual Processor arrangement for the DG/DAC unit was poor and no one at Data General could explain the extra requirements for this configuration. Therefore, no attempt was made in the code to take advantage of the dual processing set-up in the Chemical Engineering Control Laboratory.
- 4) Data General was not able to deliver the DG/DAC unit by

the promised deadline. Therefore, the code written in this project was not able to be tested.

The following were decisions which had to be made on how flexible the interface should be:

- 1) It was decided not to plan the code for the dual processing case because of the lack of documentation dealing with this arrangement.
- 2) It was decided to allow each device to be independent of the slot number in the DG/DAC unit. The user has to specify not only how many slots he is using for his application but which particular slot he is using for each device. The multiplexor still must follow the ADC device in the ADC cluster. The slot selection is done in PTAPE.
- 3) Presently, for the digital to analog converter, the user always starts with channel 0 and proceeds sequentially to channel N for the (N + 1) channels in his application. To allow for greater flexibility, and to prepare for the future dual-processing situation, it was decided to allow the user to start his application at any channel and proceed sequentially from there. The two DAC devices are treated separately and the user is required to indicate, in PTAPE, the following for each DAC unit:
 - i) the slot number of each DAC unit
 - ii) the number of channels each DAC unit is to use
 - iii) the starting channel of each DAC unit
- 4) It was decided to allow each of the voltage multiplexors

to have separate gain values. The voltage multiplexors have programmable gains which are set in the PTAPE routine. The user must also set in PTAPE, the slots in which the ADC and each multiplexor are located.

5) It was decided to treat the two TTL input and the two TTL output devices separately to allow for greater flexibility in their use.

6) It was decided to mask out the following devices when the DG/DAC unit is being serviced:

- Teletype Output (TTO)
- Teletype Input (TTI)
- Real Time Clock (RTC)
- Paper Tape Punch (PTP)
- Line Printer (LPT)

This is a change from the previous design where the Line Printer was not mask out during the servicing of the A/O converter.

7) It was decided to design the code so that future expansion could occur with minimal programming effort. The structured programming technique used in GOSEX was again used in the new code. The individual sections of code were written as conditional assemblies to allow for greater efficiency in execution.

8) In the Analog-to-Digital converter cluster the ADC module is in the first slot used by the cluster. It was decided to make the two voltage multiplexors follow in the two slots after the ADC and have the current multiplexor occupy the last slot in the cluster.

This convention was necessary for the coding of the programmable gains.

4.2 Description of the Code

The following is a discussion of the analysis done on each section of the program which had to be added or changed.*

Figure 3 shows the flow of GOSEX dealing with the interface to the I/O subsystem.

The code changes are divided into five sections:

1) Changes and additions to PREP.

PREP is the routine which checks the inputs given by the user. Since new tables have been added and others expanded, the code relating to these tables has been changed. Tables for the TTL input (TTLI1 and TTLI2) and TTL output (TTL01 and TTL02) have been added. The table for the digital-to-analog converter (ANALG) has been retained but the first four values of ANALG are now reserved for the first DAC device, while positions 5 - 8 in the ANALG table are for the second DAC device. The changed program PREP is given in figure 4.

2) Changes and additions to PTAPE.

PTAPE contains the parameters which the user changes to fit his application. The number of channels per device have been changed and new devices have been added. The slot containing each device is given to increase the flexibility of the system. For the DAC devices the starting channel number for each device is given. Also the gain values for the two voltage multiplexors is included. The changed program PTAPE is given in figure 5.

3) Changes to DCLAR

*The new code is indicated by a bar on the left side of the page for PREP, PTAPE, and OPCOM. MTPLX contains entirely new code.

DCLAR is used to initialize and start the DG/DAC unit, start the contact sense device, and set the gain values of the two voltage multiplexors. DCLAR is called by PREP in the initialization stage of GOSEX. A flowchart for DCLAR is given in figure 6 and the code is given in figure 9.

4) Changes to MTPLX

MTPLX is called when the user clock expires and the ADC device is to be started. The routine sets the relays, outputs the data to the first and second DAC devices and the two TTL output devices. The outputting of the DAC values has to be handled in the following method. The resolution of the digital data is 12-bits which occupies the left most 12 bits of the data register. The two right most bits are to contain the channel number of the DAC device in question. The digital output values are loaded into AC1, then shifted four bits left to place them in the correct bits. The channel number is then added to AC1 to give the required contents of the data register. The Specify Conversion (DOB) statement is then issued to convert the digital value to an analog signal.

After the output devices are handled the routine then starts the two TTL devices and the ADC in Data Channel Operation mode. A flowchart for MTPLX is given in figure 7 and the code is given in figure 9.

5) POLLR-Polling routine and input handler.

POLLR is called upon an interrupt from the DG/DAC unit.

The DG/DAC unit is examined to see which input device caused the interrupt and control is passed to the code which handles the interrupting device. The device can be the contact sense, ADC, or one of the two TTL input devices.

Since the interrupts are to be handled quickly all other modules of the DG/DAC unit are masked out before the inputs are handled. After the contact sense device inputs are handled the device is again started. The flow of POLLR is given in figure 8 and the code is given in figure 9.

5-

CONCLUSIONS

The prime objectives of the project have been achieved.

These were:

- a) To examine GOSEX and determine how it handles the I/O.
- b) To examine the DG/DAC unit and determine how to program it.
- c) To write code to interface the new DG/DAC subsystem with the existing code of GOSEX.
- d) To examine current Process Control Systems and comment on how each system uniquely solves the Process Control problem.

The code written is not completely transparent to the user because the DAC output devices had to be treated as separate devices compared to the previous single treatment. The DG/DAC unit was not delivered in time for the code written in this project to be tested. The documentation of the interface should allow any errors, which may occur in the testing, to be easily corrected.

5
FIGURES

Figure 1

Layout of the Hardware in the Chemical
Engineering Control Laboratory.





Figure 2

DGDAC Configuration

SLOT






Figure 3

Flow of GOSIX pertaining to the interface with the I/O subsystem




Figure 4
Changes to PREP

```

0001  PRPF
01          TITLE PRPF
02
03          /PRPF TAPE B 1 OF 2
04
05          ENTO QV114
06          ENT EXC14
07          EXTD TIMER
08          EXTH TTYPE, TASKS, ALARM, DIVID, DECOM, MESSG
09          EXTH CARDR, DESKNO, MINTR, MESS, MODE, RANGE, DCLAR
10          EXTH SUPRS, MEST, UEST, SCNR, MTPLEX, CLOOF, UDEF
11
12          IFB ACATA
13          EXTH TASK, XMTG, PRI
14          ENDC
15
16          IFB FORTY
17          EXTH FORTY, ITACH, XMTG, PRI
18          EXTH FORTN
19          ENDC
20
21          IFB ALAYS
22          EXTH RPLAR
23          ENDC
24
25          IFB D1000
26          EXTH RPLAR
27          ENDC
28
29          IFB ATQ003
30          EXTH DATUM
31          ENDC
32
33          IFB CHCT
34          EXTH CHCTE
35          ENDC
36
37          IFB

```

```

38
39
40 .DEFINITION OF EXTERNAL SYMBOLS
41
42 .TIMER  ADDR OF WORD DEFINING THE # RTC PULSES IN ONE
43         REAL TIME SECOND
44
45 .TYPE  ADDR OF BYTE POINTER TO THE AUXILIARY TELETYPE FILENAME
46
47 .TASK  ADDR OF THE USER TASK DEFN TABLE
48
49 .ALARM  ADDR OF THE USER ALARM DEFN TABLE
50
51 .DIVID  MICROVOLT SUBROUTINE CALL TO THE SINGLE PRECISION UNSIGNED
52         DIVIDE ROUTINE
53
54 .OPCODE  POINTER TO OPCODE NO FILENAME
55
56 .MSG  ADDR POINTER TO MESSAGE NO FILENAME
57
58 .ERR  MICROVOLT SUBROUTINE CALL TO THE R005 SYSTEM ERROR ROUTINE
59
60 .DISK  MICROVOLT SUBROUTINE CALL TO THE DISK MESSAGE
61         RECEIVAL ROUTINE
62
63 .ALARM  S.A. OF THE USER ALARM MONITOR
64
65 .INT  ADDR OF INTERRUPT COMMUNICATION WORD
66
67 .MODE  HALF OF WORD INDICATING THE PROGRAM MODE(ZERO-BACKGROUND,
68         NON-ZERO-FORGROUND)
69
70 .LOCATE MICROVOLT SUBROUTINE CALL TO DETERMINE THE LOCATION OF
71         A1 ADDR IN PROGRAM SPACE
72
73 .INT  S.A. OF THE COLLECTION OF USER INTERRUPTING DEVICES
74
75 .ERR  S.A. OF ERR SUBROUTINE ROUTINE

```

CODE REF

01	USERB	S.A. OF USER BUILT SYMBOL TABLE
02	UREST	END ADDR OF USER BUILT SYMBOL TABLE
03	UCFREQ	WORD SPECIFYING THE FREQUENCY OF THE USER CLOCK
04	UIRPLV	S.A. OF THE USER CLOCK INTERRUPT ROUTINE
05	UCLOPF	S.A. OF THE CONTROL LOOP DEFN TABLE
06	UDFDEF	S.A. OF THE USER DEFINED EXECUTIVE FUNCTION LIST BLOCKS
07		
08	UTASK	TASK CALL TO CREATE A PARALLEL USER TASK
09	UTXMT	TASK CALL TO TRANSMIT A MESSAGE TO ANOTHER ROUTINE
10		AND ADMIT ITS RECEPTION
11	UPRI	TASK CALL TO CHANGE THE PRIORITY OF THE CALLER
12	UPCALL	DEFINITE SUBROUTINE CALL TO FORTRAN IV
13	UTASK	S.A. OF THE FORTRAN IV ROUTINE TO CREATE A
14		PARALLEL USER TASK
15	UTXMT	S.A. OF THE FORTRAN IV ROUTINE TO TRANSMIT A
16		MESSAGE AND WAIT FOR RECEPTION
17	UPRI	S.A. OF THE FORTRAN IV ROUTINE TO CHANGE
18		THE PRIORITY OF THE CALLER
19	UPCALL	EXECUTIVE'S FORTRAN IV RUN TIME STACK POINTER
20	UPRST	ADDR OF THE READY BIT STATUS TABLE, STARTING AT BIT 0
21	UPRST	ADDR OF THE READY BIT STATUS TABLE, STARTING AT CHANNEL 0
22	UPRST	ADDR OF THE READY BIT STATUS TABLE, STARTING AT CHANNEL 0
23	UPRST	ADDR OF THE READY BIT STATUS TABLE, STARTING AT BIT 0
24	UPRST	ADDR OF THE FIRST TIL INPUT STATUS TABLE, STARTING AT BIT 0
25	UPRST	ADDR OF THE SECOND TIL INPUT STATUS TABLE, STARTING AT BIT 0
26	UPRST	ADDR OF THE FIRST TIL OUTPUT STATUS TABLE, STARTING AT BIT 0
27	UPRST	ADDR OF THE SECOND TIL OUTPUT TABLE, STARTING AT BIT 0

```

27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000

```

0005 FREE

```
01      SECOND IS STORED IN "TIMER". THE "OFCOM.MD" FILE IS CHECKED
02      IF IT DOES NOT EXIST, THE ERROR RETURN TO THE
03      RDO5 CLI IS TAKEN
04      (2) THE RDO5 INTERRUPTS TO THE PROGRAM ARE DISABLED, THE CONSOLE
05      FILENAME IS WRITTEN TO THE "CONSL" BUFFER. IF AN AUXILIARY
06      TELETYPE HAS BEEN CONFIGURED, ITS FILENAME IS WRITTEN TO
07      THE "TTYE" BUFFER
08      (3) THE PROGRAM MODE IS DISPLAYED TO THE OPERATOR. THE 'MODE'
09      ADDR IS SET TO ZERO FOR BACKGROUND AND NON-ZERO FOR
10      FOREGROUND
11      (4) THE EXISTENCE OF A SYMBOL TABLE IS VERIFIED. IF
12      NONE EXISTS, A MESSAGE IS OUTPUT AND RETURN TO THE
13      RDO5 CLI OCCURS
14      (5) IN TURN, THE INFORMATION FOR THE RELAYS, AND CONVERTERS
15      AND CONTACT SENSES IS STUDIED. IF ANY ERRORS ARE DETECTED,
16      A MESSAGE IS OUTPUT AND THE ERROR FLAG IS SET
17      IF THE DEVICE INFORMATION IS OK, THEN THE
18      THE AND AND CONTACT SENSE DEVICES ARE
19      INTRODUCED TO RDO5 AND THE USER CLOCK IS DEFINED
20      (6) NEXT, THE USER TASK DEFINITION TABLE IS STUDIED. IF IT
21      HAS ZERO LENGTH, OR IF THE S.A., PRIORITY, ID OR TASK
22      KILL DATA IS IN ERROR, A MESSAGE IS OUTPUT AND THE ERROR
23      FLAG IS SET
24      (7) THE ALARM DEFINITION TABLE IS EXAMINED. IF IN ERROR OR IF
25      THE FILE "MESSAGE.MD" IS NOT FOUND, A MESSAGE IS OUTPUT AND
26      THE ERROR FLAG IS SET
27      (8) IF THE ERROR FLAG IS SET, THEN A RETURN TO THE
28      RDO5 CLI OCCURS
29      (9) THE EXECUTIVE IS ASSIGNED A NON-ZERO ID NUMBER
30      THE ALARM MONITOR TASK IS CREATED
31      (10) AT THIS POINT, ALL IS READY TO RUN. THE OPERATOR IS
32      PROMPTED TO INITIATE ACTIVITY BY STRIKING A KEY
33      THE EXECUTIVE IS NOW IN CONTROL OF THE SYSTEM RESOURCES
```

```

34
35 00000'056403 EXC14 STA 3 2 +3 .SAME RETURN ADDR
36
37 .REAL TIME CLOCK CHECK
38 00001'000017 .SYSTEM .GET RTC FREQ
39 00002'021000 .GHZ
40 00003'000000 .RADDR
41 00004'080417 LDA 2 23004 .GET ERROR CODE
42 00005'101000 NOV 0 0 SLR .GET LOOP COUNTER
43 00006'077777 .ERROR .NO RTC
44 00007'030418 LDA 2 FREQE .GET ADDR OF FREQUENCY TABLE
45 00010'113000 ADD 0 2 .FIND ENTRY
46 00011'020000 LDA 1 0 2 .GET IT
47 00012'0140013 STA 1 TIMES .INSTALL THE #
48
49 .OPCODE NO FILENAME CHECK
50 00013'010410 LDA 0 2 +10 .GET POINTER TO OPCODE NO FILENAME
51 00014'010410 LDA 1 3CRAT .GET ADDR OF WRITE SPACE
52 00015'000017 .SYSTEM .GET FILE'S INFO
53 00016'021000 .STAT
54 00017'000000 JMP +3
55 00018'000000 JMP D400F .FILENAME OK
56 00019'010418 LDA 2 23004 .GET ERROR CODE
57 00020'000000 .ERROR
58 00021'017777 OPCODE
59

```

```

0004  PAGE
01000024 000000 SCRT  WORK
02 00025 000025 PULSE  PULSE
03 00013 000013      10
04 00027 000144      100
05 00050 001750     1000
06 00031 000075      50
07 00012 000053      30
08 00003 007004  E0004  2004
09 00014 003005  E0005  2005
10 00030 000100  E0057  400
11
12
13 00012 000017  D000F  SYATH  .DISABLE RDS INTERRUPTS TO THE PROGRAM
14 00037 001017      0013
15 00019 007777      MODE
16
17
18 00001 000000  .GET IP CONSOLE AND AUXILIARY TELETYPE
19 00041 000000  LDA 0 00000 3  .GET BYTE POINTER TO CONSOLE FILENAME
20 00041 000017  SYATH  .WRITE FILENAME TO BUFFER
21 00013 001017  .COUNT
22 00044 007777  TTYPE
23 00041 000000  LDA 1 00000  .GET CURRENT S.A. OF UST
24 00041 000000  LDA 2 00000  .GET S.A. OF BACKGROUND UST
25 00010 000000  SUB 1 3
26 00010 000000  STA 2 00000  .SAVE MODE FLAG

```

```

30
31H
32 IFB TT/3-1
33 00051 022773 LDA 0 0 -1 /GET POINTER TO AUXILIARY TELETYPE FILENAME
34 00052 008017 SYSTM /WRITE FILENAME TO BUFFER
35 00053 021017 SCOUT
36 00054 030400 030400 /ASCII <ID>NULL>
37 00055 024777 LDA 1 -1
38 00056 101004 MOV 2 2 32R /BACKGROUND?
39 00057 113400 SUB 1 1 /NO-ETTO IS AUXILIARY
40 00058 113310 MOVSR 0 3 /YES-GET ADDR OF BUFFER
41 00059 040402 STA 1 2 3 /INSTALL NECESSARY EXTENSION
42
43 ENDC
44
45 00060 101004 MOV 2 2 32R /FOREGROUND?
46 00061 000404 JMF -1 /YES
47 00062 007707 DEFNO /INDICATE BACKGROUND
48 00063 000000 HRRF0
49 00064 000404 JMF +3
50 00065 000000 DEFNO /INDICATE FOREGROUND
51 00066 000000 HRRF1
52 00067 101401 SUB 0 0 32R
53 00068 000000 GOFL0
54 00069 012777 STA 0 0 -1 /LEAD EXECUTE FLAG
55
56 /USER BUILT SYMBOL TABLE CHECK
57 00070 040400 LDA 1 POINT /GET S.A. OF SYMBOL TABLE
58 00071 010000 LDA 0 POINT-1 /GET END ADDR OF SYMBOL TABLE
59 00072 000000 MOVSR 0 0 32R /IS BEST DEFINED?
60 00073 101113 MOVSR 1 1 32R /IS BEST DEFINED?
61 00074 000404 JMF +3 /NO
62 00075 000000 SUB 0 1 32R /LAST LENGTH?
63 00076 000000 JMF +0 /YES-OK
64 00077 000000 DEFNO /INDICATE ERROR
65 00078 000000 HRRF0

```

0003	FAEF		
01	00100	000101	JMP 0 +1 ; GO ADR1
02	0000100	000000	MILIT
03	00107	100000	SUB 0 0
04	0000110	000000	LDA 2 R3
05	00111	077777	DIVID ; DETERMINE # OF SYMBOLS
06	00112	101000	MOV 0 0 ; DIV REMAINDER?
07	00113	000770	JMP -10 ; YES-ERROR
08			
09			
10			
11	00114	011110	JMP ALIAS ; RELAY CHECK
12	00115	077777	LDA 1 +10 ; GET ADDR OF RELAY BIT STATUS TABLE
13	00116	000000	RANGE ; TEST ADDR
14	00117	000000	JMP +7 ; BAD ADDR
15	0000100	000000	JMP +0 ; BAD ADDR
16	00111	000000	LDA 1 INPUT1 ; GET # RELAYS
17	0000100	000000	LDA 2 +3 ; GET # R. OF RELAY TABLE
18	00112	000000	JSR CLEAR ; CLEAR TABLE
19	00113	077777	JMP +0 ; OK
20	00114	077777	RELAT
21	00115	100100	BRING ; INDICATE ERROR
22	0000100	000000	MSG00
23	0000100	000000	JSR 6 INPUT1 ; SET NO GO FLAG
24			ENDC

24		
25		.CHECK FIRST DAC TABLE
26	IFN DTAB1	
27	LDA 1 +10	.GET ADDR OF FIRST D/A READ DATA STORAGE
28	RANGE	.TEST ADDR
29	JMP +7	.BAD ADDR
30	JMP +6	.BAD ADDR
31	LDA 1 INFO+2	.GET # OF FIRST D/A DEVICE CHANNELS
32	LDA 2 +3	.GET S.A. OF FIRST D/A DEVICE TABLE
33	JSR CLEAR	.CLEAR TABLE
34	JMP +5	.OK
35	RRALO	.ADDR OF FIRST D/A ADDRESS TABLE
36	RRRNO	.INDICATE ERROR
37	RRRNO	
38	JSR 3 INFO+11	.SET NO GO FLAG
39	ENDC	
40		
41	IFN DTAB2	.CHECK SECOND DAC TABLE
42	LDA 0 +14	.LOAD 4 INTO ACC
43	LDA 1 +12	.LOAD ADDR OF FIRST D/A DEVICE TABLE
44	ADD 0 1	.ADDR OF 2ND D/A TABLE IS 4+ADDR OF FIRST TA
45	RANGE	.TEST ADDR
46	JMP +11	.BAD ADDR
47	JMP +10	.BAD ADDR
48	LDA 1 INFO+2	.GET NO. OF SECOND D/A DEVICE CHANNELS
49	LDA 2 +4	.GET S.A. OF FIRST D/A DEVICE TABLE
50	ADD 0 2	.S.A. OF 2ND D/A TABLE IS 4+S.A. OF FIRST TA
51	JSR CLEAR	.CLEAR TABLE
52	JMP +9	.OK
53	RRALO	.ADDR OF FIRST D/A ADDR TABLE
54	+	.TO INCREMENT TO ADDR OF SECOND D/A ADDRESS T
55	RRRNO	.INDICATE ERROR
56	RRRNO	
57	JSR 3 INFO+11	.SET NO GO FLAG
58	ENDC	

0003 FREE

```

01                                     /CHECK TTL11 TABLE
02                                     IFN TL11
03 00164 004410 LDA 1 +10 /GET ADDR OF TTL11 DATA STORAGE AREA
04 00165 000147 RANGE /TEST ADDR
05 00166 000407 JMF +7 /BAD ADDR
06 00167 000406 JMF +6 /BAD ADDR
07 00170 004343 LDA 1 INFO+0 /GET NUMBER OF TTL11 ENTRIES
08 00171 000146 LDA 2 +6 /GET S A OF TTL11 TABLE
09 00172 004057 JCR CLEAR /CLEAR TABLE
10 00173 000405 JMF +5
11 000174 000000 TTL11 /ADDRESS OF TABLE
12 00175 000141 BSN0 /INDICATE ERROR
13 000176 000000 MSG102
14 00177 004340 JCR 2 INFO+11 /SET NO GO FLAG
15 ENDC
16
17
18                                     /CHECK TTL12 TABLE
19                                     IFN TL21
20 00200 004410 LDA 1 +10 /GET ADDR OF TTL12 DATA STORAGE AREA
21 00201 000146 RANGE /TEST ADDR
22 00202 000407 JMF +7 /BAD ADDR
23 00203 000406 JMF +6 /BAD ADDR
24 00204 004340 LDA 1 INFO+0 /GET NUMBER OF ENTRIES IN TTL12 TABLE
25 00205 000146 LDA 2 +6 /GET S A OF TTL12 TABLE
26 00206 004057 JCR CLEAR /CLEAR TABLE
27 00207 000405 JMF +5
28 000210 000000 TTL12 /ADDRESS OF TABLE
29 00211 000141 BSN0 /INDICATE ERROR
30 00212 000000 MSG103
31 00213 004340 JCR 2 INFO+11 /SET NO GO FLAG

```

31	ENDC	
32		
33		,CHECK TTLO1 TABLE
34	IFN TTLO	
35 00111 034410	LDA 1 +10	,GET ADDR OF TTLO1 DATA STORAGE AREA
36 00113 000201	RANGE	,TEST ADDR
37 00114 000407	JMP +7	,BAD ADDR
38 00117 000408	JMP +8	,BAD ADDR
39 00120 034510	LDA 1 INFO+7	,GET NUMBER OF TTLO1 ENTRIES
40 00121 030403	LDA 2 +3	,GET S.A. OF TTLO1 TABLE
41 00123 004517	JSR CLEAR	,CLEAR TABLE
42 00125 000405	JMP +5	
43 00128 000000	TTLO1	,ADDRESS OF TABLE
44 00129 000211	BRNG	INDICATE ERROR
45 00131 000000	NEG104	
46 00137 001510	JSR 6 INFO+11	,SET NO GO FLAG
47	ENDC	
48		
49 00130 000000		CHECK TTLO2 TABLE
50	IFN TTLO	
51 00131 034410	LDA 1 +10	,GET ADDR OF TTLO2 DATA STORAGE AREA
52 00132 000217	RANGE	,TEST ADDR
53 00133 000407	JMP +7	,BAD ADDR
54 00136 000408	JMP +8	,BAD ADDR
55 00139 034510	LDA 1 INFO+10	,GET NUMBER OF TTLO2 ENTRIES
56 00138 030403	LDA 2 +3	,GET S.A. OF TTLO2 TABLE
57 00137 004512	JSR CLEAR	,CLEAR TABLE
58 00140 000405	JMP +5	
59 00141 000000	TTLO2	,ADDRESS OF TABLE

```

0007  PAEP
01 00242 000211  DSKNG          / INDICATE ERROR
03000243 000000  MSGIOS
05 00244 000475  JBR 2 INFO+11  / SET NO GO FLAG
06
07
08
09          / A/D CONVERTER CHECK
10          IFN AT005
11 00245 004410  LDA 1  +10          / GET ADDR OF A/D READ DATA STORAGE AREA
12 00246 000332  RANGE          / TEST ADDR
13 00247 000407  JNF  +7          / BAD ADDR
14 00250 000406  JNF  +6          / BAD ADDR
15 00251 014475  LDA 1 INFO          / GET # A/D'S
16 00252 000403  LDA 2  +5          / GET S.A. OF A/D TABLE
17 00253 004475  JBR CLEAR          / CLEAR TABLE
18 00254 000405  JNF  +5
19 00255 077777  DAT00
20 00256 000242  DSKNG          / INDICATE ERROR
21000257 000000  MSG00
22 00258 004405  JBR 2 INFO+11  / SET NO GO FLAG
23
24
25          / CONTACT SENSE CHECK
26          IFN CT001
27 00261 004410  LDA 1  +10          / GET ADDR OF CONTACT SENSE DISPATCH TABLE
28 00262 004405  STA 1 POINT          / INSTALL THE POINTER
29 00263 000242  RANGE          / TEST ADDR
30 00264 000407  JNF  +10          / BAD ADDR
31 00265 000417  JNF  +17          / BAD ADDR

```

```

28 00366 0024443 LDA 1 INFO+3 ;GET # CONTACT SENSE IN SYSTEM
29 00367 0044432 STA 1 POINT+1 ;INSTALL COUNTER
30 00370 0026450 LDA 1 @ POINT ;GET A DISPATCH ADDR
31 00371 0000233 RANGE ;TEST IT
32 00372 0004415 JMP +10 ;BAD ADDR
33 00373 0004414 JMP +14 ;BAD ADDR
34 00374 101000 MOV 1 2
35 00375 102400 SUB 0 0
36 00376 041000 STA 0 0 2 ;ZERO RESOLUTION ADDR
37 00377 010441 ISZ POINT ;INCR POINTER
38 00380 014441 DSZ POINT+1 ;DONE?
39 00381 000737 JMP -11 ;NO
40 00382 0004410 JMP +10
41 00383 077777 SENSE
42 00384 000238 BSRNG ;INDICATE ERROR
43 00385 000000 MSG37
44 00386 000403 JMP +3
45 00387 000304 BSRNG ;INDICATE ENTRY ERROR
46 00388 000000 MSG37
47 00389 000000
48 00391 0004438 JSR @ INFO+11 ;SET NO GO FLAG
49 ENDC
50
51 ;DECLARE USER INTERRUPTING DEVICES
52 00391 0044432 LDA 1 POINT+10 ;GET S.A. OF DECLARATION OF USER DEVICES
53 00393 1031113 MOVLL 1 1 ENDC ;IS ADDR OK?
54 00394 000404 JMP +4 ;OK
55 00395 000307 BSRNG ;INDICATE ERROR
56 00396 000000 MSG37
57 00397 0004430 JSR @ INFO+11
58 00398 000000 LDA 0 GOFLAG
59 00399 101004 MOV 0 0 BSR ;IS NO GO FLAG SET?

```

```

0008  FAEP
01000322 0000002      JMP NOCLK+2      ,YES
02 00323 003425      JSR @ POINT+10    ,NO
03000324 0000000      JMP NEXT
04
05 00325 0000003 N3:      3
06
07000326 0000000 INFO    ATODS          ,NUMBER OF ENTRIES IN ADC TABLE
08000327 0000000      RELAYS          ,# RELAYS
09000330 0000000      DTAS1          ,# FIRST DAC
10000331 0000000      DTAS2          ,# SECOND DAC
11000332 0000000      CNTCT          ,# CONTACT SENSES
12000333 0000000      TL1I          ,# FIRST TTL INPUTS
13000334 0000000      TL2I          ,# SECOND TTL INPUTS
14000335 0000000      TL1O          ,# FIRST TTL OUTPUTS
15000336 0000000      TL2O          ,# SECOND TTL OUTPUTS
16000337 0000000      NOGO
17
18 00340 077777 POINT    QUEST
19 00341 077777          QUEST
20 00342 077777          SCAN
21 00343 077777          RTPLX
22 00344 077777          SUPRS
23 00345 077777          TASKS
24 00346 077777          ALARM
25 00347 077777          MESSG
26 00350 077777          DCLAR

```

```

27
28 00351'102400 CLEAR SUB 0 0
29 00352'124405 NEG 1 1 SHR
30 00353'001400 JNF 0 3
31 00354'041000 STA 0 0 2
32 00355'151400 INC 2 2
33 00356'123404 INC 1 1 SZR
34 00357'000775 JNF -3
35 00360'001400 JNF 0 3
36
37000351'000000 UFDTE WORK
38
39 EOT ,END OF FREE TAPE # 1 OF 2

```

0005	FREE									
GLARM	000346 X	8/24								
ANSLG	000157 X	5/35	5/53							
OTGDS	0000000	1/29	7/07	8/07						
BLUST	000035	4/10	4/23							
CHECK	0000000	3/49								
CLERR	000331	5/17	5/33	5/51	6/09	6/25	6/41	6/57	7/14	
		8/28								
CLDOP	077777 X									
CNTCT	0000000	1/33	7/23	8/11						
DATUM	000235 X	7/16								
DECLAR	000350 X	8/26								
DEMOG	0000000	4/18								
DI-15	000111 X	3/05								
DTLLE	000033	3/35	4/13							
DEFNO	000313 X	4/41	4/44	4/58	5/20	5/36	5/55	6/12	6/28	
		6/44	7/01	7/17	7/43	7/46	7/55			
DTA31	0000000	5/23	5/09							
DTA32	0000000	5/41	6/10							
DTGAS	0000000	1/29								
E2004	000033	3/41	4/03							
E2005	000034	3/34	4/09							
ERROR	000022 X	3/43	3/57	6/44						
EXC14	000000	3/35								
FOALL	077777 X									
PORT4	0000000	1/12	1/16							
FETCH	0000024									
GOLF5	0000000	4/47	7/58							
HHH1	0000000	4/41								
HHH2	000328	5/19	5/22	5/31	5/38	5/43	5/57	6/07	6/14	
		6/23	6/30	6/37	6/46	6/55	7/03	7/12	7/19	
		7/25	7/48	7/57	8/07					

ITAGI	077777 X								
K3	000323	5/04	6/03						
KILIT	0000000	5/02							
NESS	077777 X								
NESS6	000347 X	6/25							
NNITR	077777 X								
MODE	000040 X	4/15							
MSG10	0000000	5/56	6/13	6/29	6/45	7/02			
MSG60	0000000	4/42							
MSG61	0000000	4/45							
MSG62	0000000	4/59							
MSG63	0000000	5/21							
MSG64	0000000	7/18							
MSG67	0000000	7/44							
MSG80	0000000	7/47							
MSG98	0000000	5/37							
MSG99	0000000	7/58							
HTFLX	000343 X	8/21							
HECT	0000000	3/03							
NOCLP	0000000	8/01							
HOGG	0000000	8/16							
OPCON	000023 X	3/58							
QVY14	000000								
P011T	000340	4/51	4/52	7/25	7/30	7/31	7/38	7/39	7/52
		8/02	8/13						
PR1	077777 X								
PRUSE	000023	3/44	4/02	1/02					
PRUSE	000000	3/40							

0010	FREP								
RANGE	0002717X	5/12	5/28	5/43	6/04	6/20	6/36	6/52	7/09
		7/23	7/32						
RELAY	0001247X	5/19							
RLAYS	0000000	1/21	5/10	8/08					
SCAN	0001427X	8/20							
SCRAT	0000047	3/31	4/01						
SENER	000303 X	7/42							
SUPRS	000344 X	8/22							
TABLE	0000000	6/49							
TAKES	0003457X	8/23							
TIMER	0000017X	3/47							
TL11	0000000	8/02	8/12						
TL10	0000000	8/34	8/14						
TL11	0000000	8/18	8/13						
TL20	0000000	8/30	8/15						
TTL11	0000000	8/11							
TTL12	0000000	8/27							
TTL01	0000000	8/43							
TTL02	0000000	8/49	8/39						
TTYPE	000017 X	4/21							
TTL3	0000000	4/27							
UBST	0777777 X								
UBST	0003417X	8/13							
UBD16	000381	8/37							
UBST	000340 X	8/18							
UBST	0000000	4/22							
UBST	0000000	4/01	8/37						
UNITA	0777777 X								
UNIT	0777777 X								
UNIT	0777777 X								
UNIT	0777777 X								

Figure 5
Changes to PTAPE

```

0001  MAIN
01      , GOSEX PARAMETER TAPE
02
03      , USERS OF THE GOSEX EXECUTIVE MUST CONFIGURE ALL OF
04      , THE EXECUTIVE PROGRAMS WITH THIS PARAMETERS TAPE
05      , THE USER MAY SPECIFY THE VALUE OF A CERTAIN NUMBER
06      , OF THE PARAMETERS HEREIN.  THESE PARAMETERS ARE.
07      ,      LPTS      -MIN=0, MAX=2
08      ,      TTYS      -MIN=1, MAX=2
09      ,      PTFB      -MIN=0, MAX=2
10      ,      DRFL      -MIN=1, MAX=8
11      ,      CASS      -MIN=0, MAX=8
12      ,      MAGS      -MIN=0, MAX=8
13      ,      PORTA
14      ,      NVTYPE     -MIN=0, MAX=7
15
16      , ASIDE FROM THE ABOVE PARAMETERS, THE ONLY OTHER ONES THAT MAY
17      , BE REASSIGNED NEW VALUES ARE THOSE WHICH APPLY TO THE
18      , PERIPHERAL DEVICES INTERFACING THE CPU TO THE PILOT PLANT
19      , THESE ARE LISTED AT THE END OF THIS PARAMETER TAPE
20
21      , DISPLACEMENTS IN THE GENERAL WORK SPACE
22
23      000012 DWSR  GENRAL- 10      , SIZE OF GENERAL WORK SPACE
24      000000 DWSR  RETUR-  0      , RETURN ADDRESS STORAGE
25      000001 DWSR  RETADR-  1      , RETURN ADDR STORAGE
26      000002 DWSR  BYTER-  2      , BYTE POINTER STORAGE
27      000003 DWSR  COUNT-  3      , COUNTER
28      000004 DWSR  PCOUNT-  4      , COUNTER
29      000005 DWSR  WORD1-  5      , TEMPORARY STORAGE
30      000006 DWSR  WORD2-  6      , TEMPORARY STORAGE
31      000007 DWSR  WORD3-  7      , TEMPORARY STORAGE
32      000008 DWSR  WORD4-  8      , TEMPORARY STORAGE
33      000009 DWSR  WORD5-  9      , TEMPORARY STORAGE
34

```



```

0002  MAIN
01      , DISPLACEMENTS IN THE DEVICE STATUS TABLE
02
03      000000  DUSR  TABSA=  0      , DEVICE STORAGE BLOCK & A
04      000001  DUSR  IDENTA=  1      , TASK IDENTIFICATION NUMBER
05      000002  DUSR  PRIOR=  2      , TASK PRIORITY
06
07      , CONSTANTS WHICH ARE USED TO DEFINE DISPLACEMENTS
08      , FOR THE DISK MESSAGE ROUTINE
09
10      000012  DUSR  THESSA=  GENAL   , TOTAL NUMBER OF MESSAGES IN DISK FILE
11      000013  DUSR  MXLST=  GENAL+1 , MAXIMUM MESSAGE LENGTH PERMITTED
12      000014  DUSR  DSNCL=  GENAL+2 , CHANNEL # TO DISK FILE
13      000015  DUSR  DSNMF=  GENAL+3 , BYTE POINTER TO DISK FILE NAME
14      000016  DUSR  DEVEL=  GENAL+4 , CHANNEL # TO OUTPUT DEVICE
15      000017  DUSR  DEVNF=  GENAL+5 , BYTE POINTER TO OUTPUT DEVICE NAME
16      000020  DUSR  BUFR=  GENAL+6 , BYTE POINTER TO BUFFER AREA OF LENGTH MXLST
17      000000  DUSR  HIBYF=  0      , HIGH ORDER BYTE POINTER TO MESSAGE
18      000001  DUSR  LOBYF=  1      , LOW ORDER BYTE POINTER TO MESSAGE
19      000002  DUSR  LNGB=  2      , MESSAGE LENGTH IN BYTES
20
21      , DISPLACEMENTS IN THE USER TASKS DEFINITION BLOCKS.
22      , EACH BLOCK IS FOUR WORDS LONG AND EACH USER TASK HAS
23      , ONE BLOCK DEFINING ITS NECESSARY ATTRIBUTES.
24
25      000000  DUSR  TSKSA=  0      , S. A. OF THE TASK
26      000001  DUSR  TSKPR=  1      , PRIORITY OF THE TASK (1 TO 377-NEVER 0)
27      000002  DUSR  TSKID=  2      , TASK IDENTIFICATION CODE-1 TO 300,
28      , NEVER 0 OR ABOVE 300
29      000003  DUSR  TSKIL=  3      , TASK'S KILL FLAG
30      , THE TASK DEFINITION BLOCK IS EXTENDED BY ONE WORD
31      , IF THE FORT4 PARAMETER, DEFINED BELOW IS NON-ZERO
32      000004  DUSR  TSKID=  4      , TASK MODE-IF FORTRAN IV TASK, ZERO
33      , -IF ASSEMBLER ONLY, NON-ZERO

```

```

34
35      , THE FOLLOWING CONSTANTS DEFINE THE SYSTEM CONFIGURATION
36      , ZERO          DEVICE NOT IN THE SYSTEM
37      , NON-ZERO      NUMBER OF DEVICES CONFIGURED IN SYSTEM
38
39      000001 DUSR  LP1SA= 1      , LINE PRINTER
40      000001 DUSR  TTYSA= 1      , # TELETYPES ON CPU
41      000000 DUSR  FTFSA= 0      , PAPER TAPE PUNCH
42      000002 DUSR  DNFLA= 2      , DISK FILES
43      000000 DUSR  CASB= 0      , CASSETTE TAPE FILE
44      000000 DUSR  MAGSA= 0      , MAGNETIC TAPE FILE
45
46      , RDO# DISPLACEMENTS USED BY THE GOEX PACKAGE
47
48      000010 DUSR  USIP= 10      , POINTER TO CURRENT PROGRAM'S UST
49      000010 DUSR  TID= 10      , TASK ID IN TASK'S TCB
50      000014 DUSR  USTC= 14      , CURRENT TCB POINTER TO PROGRAM'S UST
51      000017 DUSR  USIN= 17      , START OF USER NREL CODE IN UST
52
53
54      , FORTRAN IV PARAMETER
55      , WHEN ZERO, ALL TASKS MUST BE IN ASSEMBLER
56      , WHEN NON-ZERO, THIS PARAMETER SPECIFIES THE MAXIMUM NUMBER OF
57      , PARALLEL FORTRAN IV TASKS THAT MAY RUN AT ONE TIME. THE
58      , EXECUTIVE MUST BE INCLUDED IN THIS COUNT. THE TOTAL NUMBER
59      , OF TCB'S IS STILL SPECIFIED BY THE ALDR LOCAL SWITCH "N"

```

```

0005  MAIN
01
02      000002  DUSR  FORT4=    2
03
04      ; CONTROLLER BLOCK DISPLACEMENTS
05
06      000012  DUSR  WNSP=    GENAL    , WORK SPACE-2 WORDS
07      000014  DUSR  SIGN=    GENAL+2  , SIGN STORAGE
08      000015  DUSR  EROR0=    GENAL+3  , ERROR AT T
09      000016  DUSR  EROR1=    GENAL+4  , ERROR AT T-1
10      000017  DUSR  EROR2=    GENAL+5  , ERROR AT T-2
11      000020  DUSR  EROR3=    GENAL+6  , ERROR AT T-3
12      000021  DUSR  ITSUM=    GENAL+7  , INTEGRAL SUM STORAGE
13      000022  DUSR  OUTPT=    GENAL+8  , CURRENT OUTPUT ACTION
14      000023  DUSR  SMOOTH=    GENAL+9  , FILTERED DATA STORAGE
15      000024  DUSR  CNTHI=    GENAL+10  , HIGH LIMIT ALARM COUNTER
16      000025  DUSR  CNTLO=    GENAL+11  , LOW LIMIT ALARM COUNTER
17      000026  DUSR  FILTR=    GENAL+12  , FILTER CONSTANT
18      000027  DUSR  VARLE=    GENAL+13  , ADDR OF RAW DATA
19      000030  DUSR  INHI=    GENAL+14  , INPUT HIGH LIMIT
20      000031  DUSR  INLO=    GENAL+15  , INPUT LOW LIMIT
21      000032  DUSR  MESHI=    GENAL+16  , MESSAGE # FOR HIGH LIMIT ALARM IN MESSG MG
22      000033  DUSR  MESLO=    GENAL+17  , MESSAGE # FOR LOW LIMIT ALARM IN MESSG MG
23      000034  DUSR  AWAIT=    GENAL+18  , INTERVAL BETWEEN SUCCESSIVE ALARMS
24      000035  DUSR  SETPT=    GENAL+19  , SET POINT
25      000036  DUSR  KP=    GENAL+20   , PROPORTIONAL GAIN
26      000037  DUSR  KPD=    GENAL+21   , PROPORTIONAL DERIVATIVE GAIN
27      000040  DUSR  KPI=    GENAL+22   , PROPORTIONAL INTEGRAL GAIN
28      000041  DUSR  SCALE=    GENAL+23  , SCALE FACTOR WITH ACTION DIRECTION
29      000042  DUSR  DELAY=    GENAL+24  , TIME INTERVAL BETWEEN CONTROL ACTIONS
30      000043  DUSR  CASCD=    GENAL+25  , CASCADE FLAG
31      000044  DUSR  DESTH=    GENAL+26  , ADDR OF DESTINATION DATA BLOCK OR
32      , D/A CHANNEL #_____

```

```

33      000045 DUSR  OUTHI=  GENAL+27 ,HIGH LIMIT ON OUTPUT
34      000046 DUSR  OUTLO=  GENAL+28 ,LOW LIMIT ON OUTPUT
35      000047 DUSR  MEAN=   GENAL+29 ,MEAN OUTPUT VALUE
36      000050 DUSR  SPOCN=  GENAL+30 ,ADDR OF CONSTANT BLOCK FOR SETPT CONVERSION
37      000051 DUSR  SPAZE=  GENAL+31 ,ADDR OF ROUTINE TO CONVERT FROM
38                          ,A/D TO ENGINEERING UNITS
39      000052 DUSR  SPEZA=  GENAL+32 ,ADDR OF ROUTINE TO CONVERT FROM
40                          ,ENGINEERING TO A/D UNITS
41      000053 DUSR  SPCAP=  GENAL+33 ,MESSAGE # FOR SETPT CAPTION IN OPDOM MG
42      000054 DUSR  MNCON=  GENAL+34 ,ADDR OF CONSTANT BLOCK FOR MEAN CONVERSION
43      000055 DUSR  MNAZE=  GENAL+35 ,ADDR OF ROUTINE TO CONVERT FROM
44                          ,D/A (OR A/D) TO ENGINEERING UNITS
45      000056 DUSR  MNEZA=  GENAL+36 ,ADDR OF ROUTINE TO CONVERT FROM
46                          ,ENGINEERING TO D/A (OR A/D) UNITS
47      000057 DUSR  MNCAP=  GENAL+37 ,MESSAGE # FOR MEAN CAPTION IN OPDOM MG
48      000060 DUSR  LFNES=  GENAL+38 ,LOOP 'S DESCRIPTIVE MESSAGE # IN OPDOM MG
49
50
51      ,DEFINITION OF PERIPHERAL DEVICES INTERFACING CPU TO THE PILOT PLANT
52      ,THE ANALOG DEVICES ARE ASSUMED TO COVER THE RANGE 0 TO 10 VDC.
53
54      000060 DUSR  ATODI=  14      ,A/D CONVERTER-ANALOG INPUT
55      000777 DUSR  INIRCH= 777      ,RANGE OF THE ANALOG INPUT DEVICE-POSITIVE
56      000004 DUSR  BTAS1=  4        ,FIRST D/A CONVERTER-ANALOG OUTPUT
57      000004 DUSR  BTAS2=  4        ,SECOND D/A CONVERTER-ANALOG OUTPUT
58      000777 DUSR  AODRG=  777      ,RANGE OF THE ANALOG OUTPUT DEVICE-POSITIVE
59      000000 DUSR  RELAYS=  16      ,RELAYS

```

```

0004  MAIN
01 000020 DUSR CINTCT- 16 ,CONTACT SENSE
02 000020 DUSR TL11- 16 ,FIRST TTL INPUT DEVICE
03 000020 DUSR TL21- 16 ,SECOND TTL INPUT DEVICE
04 000020 DUSR TL10- 16 ,FIRST TTL OUTPUT DEVICE
05 000020 DUSR TL20- 16 ,SECOND TTL OUTPUT DEVICE
06
07 ,STARTING CHANNELS OF THE DAC DEVICES
08 000000 DUSR SDA1- 0 ,STARTING CHANNEL OF THE FIRST DAC DEVICE
09 000000 DUSR SDA2- 0 ,STARTING CHANNEL OF THE SECOND DAC DEVICE
10
11 ,SLOT IN WHICH EACH DEVICE IS LOCATED
12 000000 DUSR SADR- 0 ,ADC SLOT
13 000001 DUSR SVMI- 1 ,FIRST VOLTAGE MPX SLOT
14 000002 DUSR SVMI- 2 ,SECOND VOLTAGE MPX SLOT
15 000003 DUSR SCMP- 3 ,CURRENT MPX SLOT
16 000004 DUSR SDAC1- 4 ,FIRST DAC SLOT
17 000005 DUSR SDAC2- 5 ,SECOND DAC SLOT
18 000006 DUSR STI1- 6 ,FIRST TTL INPUT SLOT
19 000007 DUSR STI2- 7 ,SECOND TTL INPUT SLOT
20 000010 DUSR STO1- 8 ,FIRST TTL OUTPUT SLOT
21 000011 DUSR STO2- 9 ,SECOND TTL OUTPUT SLOT
22 000012 DUSR SRLY- 10 ,RELAY SLOT
23 000013 DUSR SCNT- 11 ,CONTACT SENSE SLOT
24

```

```

25                                     , INDICATE THE GAIN VALUES OF THE VOLTAGE MPX
26 000001 DUSEF GAIN1= 1              , FIRST VOLTAGE MULTIPLEXOR GAIN VALUE
27 000002 DUSEF GAIN2= 2              , SECOND VOLTAGE MULTIPLEXOR GAIN VALUE
28
29                                     , OUTPUT BUFFER SIZE DEFINITIONS
30 ,WARNING: MINIMUM BUFFER SIZE MUST BE 11. IF A
31 ,         DEVICE IS CONFIGURED FOR USE
32
33 000017 DUSEF NVOL= 10               , CONSOLE
34 000000 DUSEF NVTT= 0                , AUXILLIARY TTY
35 000030 DUSEF NVLF= 40               , LINE PRINTER
36 000000 DUSEF NVFM= 0                , PAPER TAPE PUNCH
37 000050 DUSEF NVDR= 40               , DISK
38 000000 DUSEF NVCS= 0                , CASSETTE
39 000000 DUSEF NVMS= 0                , MAGNETIC TAPE
40 000000 DUSEF NVAND= 0               , ANALOG OUTPUTS. THE CHART OUTPUT TASK CLAIM
41                                     , THE FIRST NVAND ANALOG OUTPUT CHANNELS
42                                     , SPECIFIED BY DTDS ABOVE.
43
44                                     ,END OF GOSSEX PARAMETER TAPE

```

Flow of DCLAR







Figure 7










Figure 9
New MPLX Routine

```

0001  MTFLEX
01      TITL MTFLEX
02
03      , DDDAC INITIALIZATION , USER CLOCK , AND
04      , DEVICE INTERRUPT HANDLERS
05
06      ENT DCLAR, MTFLEX
07      EXTN RELAY, DATUM, SENSE, ANALG, TTLO1, TTLO2, TTLI1, TTLI2
08      EXTN ERROR, IXNT, UCX, UIEX
09
10      NREL
11
12      , DEFINITION OF ENTRY SYMBOLS
13      , MTFLEX      S. A. OF THE USER CLOCK ROUTINE
14      , DCLAR      S. A. OF THE DECLARATION OF THE DDDAC INTERRUPT
15
16      , DEFINITION OF EXTERNAL SYMBOLS
17      , RELAY      ADDR OF RELAY BIT STATUS TABLE, STARTING AT BIT 0
18      , DATUM      ADDR OF A/D READ DATA BLOCK FOR BOTH D/A DEVICES
19      , SENSE      ADDR OF CONTACT SENSE DISPATCH TABLE
20      , ANALG      ADDR OF D/A OUTPUT DATA BLOCK, FOR BOTH D/A DEVICES
21      , TTLO1      ADDR OF FIRST TTL OUTPUT DATA BLOCK
22      , TTLO2      ADDR OF SECOND TTL OUTPUT DATA BLOCK
23      , TTLI1      ADDR OF FIRST TTL INPUT DATA BLOCK
24      , TTLI2      ADDR OF SECOND TTL INPUT DATA BLOCK
25      , ERROR      MNEMONIC SUBROUTINE CALL TO THE FATAL ERROR HANDLER
26      , IXNT      SYSTEM CALL TO TRANSMIT A MESSAGE FROM A USER
27      ,           DEVICE HANDLER TO A USER TASK
28      , UCX        SYSTEM CALL TO EXIT A USER CLOCK
29      , UIEX       SYSTEM CALL TO EXIT A USER DEVICE INTERRUPT HANDLER
30
31      , WRITTEN AUGUST, 1977 BY
32      ,           DAVID SIMMONS
33
34      , WRITTEN IN DEC'S NOVA-LINE ASSEMBLER LANGUAGE FOR
35      , RDS COMPATIBILITY

```

37A00000'054000	DECLR	STA 3 RADDR	,SAVE RETURN ADDRESS
38			,DEFINE THE DGDAC UNIT TO THE SYSTEM
39 00001'020406		LDA 0 +6	,ACC CONTAINS THE DEVICE CODE
40 00002'024406		LDA 1 +6	,ACL CONTAINS THE ADDRESS TO BRANCH ON
41			,INTERRUPTS
42 00003 006017		SYSTEM	,DEFINE THE DGDAC UNIT TO THE SYSTEM
43 00004'021007		. IDEF	
44 00005'077777		ERROR	
45 00006'000403		JMP +3	
46A00007'000000		DAC	,MNEMONIC OF DGDAC DEVICE
47 00010'000323		FOLLD	,BRANCH TO FOLLD UPON AN INTERRUPT FROM DGDAC
48000011'000100		NIDS DAC	,START THE DG/DAC DEVICE
490		. IFN CNTCT	,INITIALIZE THE CONTACT SENSE DEVICE
50000012'060400		DIA 0 DAC	,READ AND SAVE THE STATUS OF THE DG/DAC
51			,CONTROLLER
52000013'030000		LDA 2 SENS	,LOAD THE SLOT ADDRESS OF THE CONTACT
53			,SENSE DEVICE
54A00014'024000		LDA 1 SFADC	,CF=1, ID=1, CR=0, LOAD 1,000,000,010,000,000
55 00013 133000		ADD 1 2	,SETUP TO LOCATE THE CONTACT SENSE DEVICE
56000016'071100		DOAS 2 DAC	,SELECT AND START THE CONTACT SENSE DEVICE
57000017'063000		DOC 0 DAC	,RESTORE THE STATE OF THE DGDAC CONTROLLER
58A		ENDC	
59			

0002	NTPLX		
01			
06D		IFN SVN1	/SET THE GAIN VALUE OF THE FIRST VOLTAGE MPX
03A00020	020000	LDA 0 SPMXA	/MUX NO=1,MUX CHAN=0
04U00021	033000	DAC 0 DAC	/SELECT THE FIRST MPX
05U00022	020000	LDA 0 GAIN1	
06U00023	022000	DDB 0 DAC	/SPECIFY THE GAIN OF THE FIRST VOLTAGE MPX
07K		ENDC	
08			
09			
10J		IFN SVN2	/SET THE GAIN VALUE OF THE SECOND VOLTAGE MPX
11A00024	020000	LDA 0 SPMX2	/MUX NO=2,MUX CHAN=0
12U00025	033000	DAC 0 DAC	/SELECT THE SECOND MPX
13U00026	020000	LDA 0 GAIN2	
14U00027	022000	DDB 0 DAC	/SPECIFY THE GAIN OF THE SECOND VOLTAGE MPX
15K		ENDC	
16			
17A00028	002000	JMP @ RADD4	/RETURN
18			
19A00031	054000	NTPLX STA 3 RADD4	/SAVE RETURN ADDRESS
20			/HANDLE THE RELAY OUTPUTS
21D		IFN RELAYS	
22 00V32	192400	SUB 2 2	/SETUP BIT COUNTER
23A00033	034000	LDA 3 R5	/GET ADD4 OF RELAY BIT STATUS TABLE
24U00034	021000	LDA 0 R5+1	/GET # RELAYS IN SYSTEM
25 00V33	010000	DEC 0 0	/MAKE LOOP COUNTER
26 00V34	020000	LDA 1 0 3	/GET A BIT FLAG, STARTING AT BIT 0
27 00V37	120004	MOV 1 1 32K	/IS BIT TO BE SET?

25 00040 151141	MOVOL 2 2 SRP	,YES-SET IT IN COMPOSITE
26 00041 151130	MOVOL 2 2	,NO-RESET IT IN COMPOSITE
30 00042 175400	INC 3 3	,PUSH POINTER
31 00043 101404	INC 0 0 SZR	,SCAN DONE?
32 00044 1000772	JMP -6	,NO-CONTINUE
33A00045 1020000	LDA 0 RS+1	,GET # RELAY BITS SCANNED
34A00046 1024000	LDA 1 N16	,GET NEG OF # OF RELAY BITS IN SYSTEM
35 00047 107003	ADD 0 1 SNR	,ANY BITS NOT SCANNED
36 00050 1000404	JMP +4	
37 00051 151130	MOVOL 2 2	,MOV COMPOSITE ALONG
38 00052 125404	INC 1 1 SZR	
39 00053 1000776	JMP -2	
40B00054 1080400	DIA 0 DAC	,SAVE THE STATUS OF THE DGDAC CONTROLLER
41B00055 1034000	LDA 3 SRLY	,LOAD THE SLOT ADDRESS OF THE RELAY DEVICE
42A00056 1024000	LDA 1 SPADR	,CP=1, ID=1, CM=0 LOAD 1,000,000,010,000,000
43 00057 1137000	ADD 1 3	,SETUP TO LOCATE THE RELAY DEVICE
44B00058 1075000	DCA 3 DAC	,SELECT THE RELAY DEVICE
45B00061 072100	DOBS 2 DAC	,SETS BIT PATTERN AND STARTS THE RELAY DEVIC
46B00062 1053000	DCC 0 DAC	,RESTORE THE STATE OF THE DGDAC CONTROLLER
47B	ENDC	
48		
49B		,HANDLE THE FIRST DAC DEVICE
50B00063 1070400	IFN DTAS1	
51A00064 050000	DIA 2 DAC	,READ THE STATUS OF THE DGDAC CONTROLLER
52B00065 050000	STA 2 DGDCA	,SAVE THE STATUS OF THE DGDAC CONTROLLER
53A00066 050000	LDA 2 SPADR	,LOAD THE FIRST SLOT ADDRESS OF THE DAC DEVI
54A00067 1024000	LDA 1 SPADR	,CP=1, ID=1, CM=0 LOAD 1,000,000,010,000,000
55 00067 1135000	ADD 1 2	,SETUP TO LOCATE THE FIRST DAC DEVICE
56B00070 074000	LDA 1 SDRA1	,LOAD THE STARTING CHANNEL OF THE FIRST DAC
57A00071 044000	STA 1 CNDAC	,STORE THE CHANNEL NUMBER OF THE DAC
58A00072 1024000	LDA 3 DIA	,GET THE ADDRESS OF THE D/A OUTPUT TABLE
59A00073 1010000	LDA 0 DIA+1	,GET THE NUMBER OF DAC CHANNELS FOR FIRST DE
60 00074 100000	REG 0 0	,START LOAD COUNTER

```

0003 RTFLY
01 00075 1035400      LDA 1 0 3      ,GET AN OUTPUT VALUE
02 0000076 1071000    DDB 2 DAC      ,SELECT THE FIRST DAC DEVICE
03 0000077 1040000    STA 0 LOOPC     ,STORE LOOP COUNTER
04 000100 1020000    LDA 0 CHDAC     ,LOAD NEXT CHANNEL NUMBER
05 00101 1125120      MOVZL 1 1     ,SHIFT
06 00102 1125120      MOVZL 1 1     ,DIGITAL OUTPUT
07 00103 1125120      MOVZL 1 1     ,FOUR BITS
08 00104 1125120      MOVZL 1 1     ,LEFT
09 00105 107000      ADD 0 1        ,MERGE VALUES FOR DATA TRANSFER
10 000106 102000      DDB 1 DAC      ,SPECIFY CONVERSION
11 00107 1101400      INC 0 0        ,INCREMENT CHANNEL NUMBER
12 00110 1040571      STA 0 CHDAC     ,STORE CHANNEL NUMBER
13 00111 1175100      INC 3 3        ,INCREMENT TABLE POSITION
14 00112 1020598      LDA 0 LOOPC     ,RESTORE LOOP VALUE
15 00113 101 34       INC 0 0 BZF     ,DONE?
16 00114 000715       JNF -15        ,NO
17 00115 1030345      LDA 2 DDBCON    ,LOAD THE STATE OF THE DDBAC CONTROLLER
18 00116 1073000      DDB 2 DAC      ,RESTORE THE STATE OF THE DDBAC CONTROLLER
19
20
21
22 IFN DTAB2
23 0000117 070400     DIA 2 DAC      ,READ THE STATUS OF THE DDBAC CONTROLLER
24 00120 010300       STA 2 DDBCON    ,SAVE THE STATUS OF THE DDBAC CONTROLLER
25 0000121 100000     LDA 2 DBDFA2    ,LOAD THE FIRST SLOT ADDRESS OF THE DAC DEVICE

```

25 00122 024534	LDA 1 SPADL	,CP=1, ID=1, CM=0 LOAD 1,000,000,010,000,000
26 00123 033000	ADD 1 2	,SETUP TO LOCATE THE SECOND DAC DEVICE
27 00124 024000	LDA 1 SCDA2	,LOAD THE STARTING CHANNEL OF THE SECOND DAC
28 00125 044354	STA 1 CNDAC	,STORE THE CHANNEL NUMBER OF THE DAC
29 00126 034506	LDA 3 D2A	,GET THE ADDRESS OF THE D/A OUTPUT TABLE
30 00127 024404	LDA 1 +4	,ADD 4 TO ADDRESS OF THE D/A OUTPUT TABLE
31 00130 037000	ADD 1 3	,TO FIND STARTING LOCATION FOR SECOND DAC DEV
32 00131 020585	LDA 0 D2A+2	,GET THE NUMBER OF DAC CHANNELS FOR SECOND DE
33 00132 000400	NEG 0 0	,START LOOP COUNTER
34 00133 025400	LDA 1 0 3	,GET AN OUTPUT VALUE
35 00134 071000	DOA 2 DAC	,SELECT THE SECOND DAC DEVICE
36 00135 040543	STA 0 LOOPC	,STORE LOOP COUNTER
37 00136 020543	LDA 0 CNDAC	,LOAD NEXT CHANNEL NUMBER
38 00137 025120	MOVZL 1 1	,SHIFT
39 00140 025120	MOVZL 1 1	,DIGITAL OUTPUT
40 00141 025120	MOVZL 1 1	,FOUR BITS
41 00142 025120	MOVZL 1 1	,LEFT
42 00143 007000	ADD 0 1	,MERGE VALUES FOR DATA TRANSFER
43 00144 086000	DOE 1 DAC	,SPECIFY CONVERSION
44 00145 001400	INC 0 0	,INCREMENT CHANNEL NUMBER
45 00146 040533	STA 0 CNDAC	,STORE CHANNEL NUMBER
46 00147 073400	INC 3 3	,INCREMENT TABLE POSITION
47 00150 020530	LDA 0 LOOPC	,RESTORE LOOP VALUE
48 00151 001404	INC 0 0 32A	,DONE?
49 00152 000780	JMP -13	,NO
50 00153 030527	LDA 2 DOCON	,LOAD THE STATE OF THE DOOAC CONTROLLER
51 00154 073000	DOE 2 DAC	,RESTORE THE STATE OF THE DOOAC CONTROLLER
52	ENDC	
53		,HANDLE THE FIRST TTL OUTPUT DEVICE
54	IFN TLIO	
55 00155 033400	SUB 3 2	,SETUP BIT COUNTER
56 00156 034341	LDA 3 FTTL0	,GET ADDR OF RELAY BIT STATUS TABLE
57 00157 020041	LDA 0 FTTL0+1	,GET # RELAYS IN SYSTEM
58 00160 000400	NEG 0 0	,MAKE LOOP COUNTER
59 00161 021400	LDA 1 0 3	,GET A BIT FLAG STARTING AT BIT 0

```

0004 MFLX
01 00182 125004 MOV 1 1 SZR ,IS BIT TO BE SET?
02 00183 151191 MOVCL 2 2 SKF ,YES-SET IT IN COMPOSITE
03 00184 151120 MOVZL 2 2 ,NO-RESET IT IN COMPOSITE
04 00185 175400 INC 3 3 ,PUSH POINTER
05 00186 101404 INC 0 0 SZR ,SCAN DONE?
06 00187 000773 JMF -6 ,NO-CONTINUE
07 00170 020530 LDA 0 FTTLO+1 ,GET # RELAY BITS SCANNED
08 00171 024503 LDA 1 NLS ,GET NEG OF # OF RELAY BITS IN SYSTEM
09 00172 107005 ADD 0 1 SNR ,ANY BITS NOT SCANNED
10 00173 000404 JMF +4 ,NOV COMPOSITE ALONG
11 00174 151120 MOVZL 2 2 ,NOV COMPOSITE ALONG
12 00175 125404 INC 1 1 SZR
13 00176 000773 JMF -2
14 00177 060400 DIA 0 DAC ,SAVE THE STATUS OF THE DODAC CONTROLLER
15 00178 034000 LDA 3 ST01 ,LOAD THE SLOT ADDRESS OF THE FIRST TTL OUTFI
16 00179 024475 LDA 1 SPADC ,CP=1, ID=1, CM=0 LOAD 1,000,000,010,000,000
17 00202 137000 ADD 1 3 ,SETUP TO LOCATE THE RELAY DEVICE
18 00203 075000 DDA 3 DAC ,SELECT THE FIRST TTL OUTPUT DEVICE
19 00204 072100 DOBS 2 DAC ,SETS THE FIRST TTL OUTPUT DEVICE
20 00205 053000 DDC 0 DAC ,RESTORE THE STATE OF THE DODAC CONTROLLER
21K ENDC
22 ,HANDLE THE SECOND TTL OUTPUT DEVICE
23 IFN TL20
24 00206 152400 SUB 3 2
25 00207 034012 LDA 3 ST1LO ,GET ADDR OF RELAY BIT STATUS TABLE

```

25 00210 020712	LDA 0 STTLO+1	,GET # RELAYS IN SYSTEM
26 00211 000400	NEG 0 0	,MAKE LOOP COUNTER
28 00212 025400	LDA 1 0 3	,GET A BIT FLAG, STARTING AT BIT 0
29 00213 025004	MOV 1 1 81R	,IS BIT TO BE SET?
30 00214 051141	MOVCL 2 2 81R	,YES-SET IT IN COMPOSITE
31 00215 051120	MOVCL 2 2	,NO-RESET IT IN COMPOSITE
32 00216 075400	INC 3 3	,PUSH POINTER
33 00217 001404	INC 0 0 81R	,SCAN DONE?
34 00220 000772	JMP -5	,NO-CONTINUE
35 00221 020501	LDA 0 STTLO+1	,GET # RELAY BITS SCANNED
36 00222 034452	LDA 1 N18	,GET NEG OF # OF RELAY BITS IN SYSTEM
37 00223 037005	ADD 0 1 81R	,ANY BITS NOT SCANNED
38 00224 000404	JMP +4	
39 00225 051120	MOVCL 2 2	,MOV COMPOSITE ALONG
40 00226 035404	INC 1 1 81R	
41 00227 000772	JMP -2	
42 00230 030400	DIA 0 DAC	,SAVE THE STATUS OF THE DGDAC CONTROLLER
43 00231 034000	LDA 3 ST02	,LOAD THE SLOT ADDRESS OF THE SECOND TTL OUT
44 00232 014444	LDA 1 8PADC	,CP=1, ID=1, CM=0 LOAD 1,000,000,010,000,000
45 00233 037000	ADD 1 3	,SETUP TO LOCATE THE RELAY DEVICE
46 00234 075400	DCA 3 DAC	,SELECT THE SECOND TTL OUTPUT DEVICE
47 00235 075100	DOBS 2 DAC	,SETS THE SECOND TTL OUTPUT DEVICE
48 00236 035000	DCC 0 DAC	,RESTORE THE STATE OF THE DGDAC CONTROLLER
49	ENDC	
50		,START THE FIRST TTL INPUT DEVICE
51		
52 00237 030400	DIA 0 DAC	,READ AND SAVE THE STATUS OF THE DGDAC CONTR
53 00238 034000	LDA 2 ST01	,LOAD THE SLOT ADDRESS OF THE FIRST TTL INPU
54 00239 014444	LDA 1 8PADC	,CP=1, ID=1, CM=0
55 00240 035000	ADD 1 2	,SETUP TO LOCATE THE FIRST TTL INPUT DEVICE
56 00241 075100	DCA 2 DAC	,SELECT AND START THE FIRST TTL INPUT DEVICE
57 00242 035000	DCC 0 DAC	,RESTORE THE STATE OF THE DGDAC CONTROLLER
58	ENDC	
59		,START THE SECOND TTL INPUT DEVICE

```

00000000 00000000
00000001 00000000
00000002 00000000
00000003 00000000
00000004 00000000
00000005 00000000
00000006 00000000
00000007 00000000
00000008 00000000
00000009 00000000
0000000A 00000000
0000000B 00000000
0000000C 00000000
0000000D 00000000
0000000E 00000000
0000000F 00000000
00000010 00000000
00000011 00000000
00000012 00000000
00000013 00000000
00000014 00000000
00000015 00000000
00000016 00000000
00000017 00000000
00000018 00000000
00000019 00000000
0000001A 00000000
0000001B 00000000
0000001C 00000000
0000001D 00000000
0000001E 00000000
0000001F 00000000
00000020 00000000
00000021 00000000
00000022 00000000
00000023 00000000
00000024 00000000
00000025 00000000
00000026 00000000
00000027 00000000
00000028 00000000
00000029 00000000
0000002A 00000000
0000002B 00000000
0000002C 00000000
0000002D 00000000
0000002E 00000000
0000002F 00000000
00000030 00000000
00000031 00000000
00000032 00000000
00000033 00000000
00000034 00000000
00000035 00000000
00000036 00000000
00000037 00000000
00000038 00000000
00000039 00000000
0000003A 00000000
0000003B 00000000
0000003C 00000000
0000003D 00000000
0000003E 00000000
0000003F 00000000
00000040 00000000
00000041 00000000
00000042 00000000
00000043 00000000
00000044 00000000
00000045 00000000
00000046 00000000
00000047 00000000
00000048 00000000
00000049 00000000
0000004A 00000000
0000004B 00000000
0000004C 00000000
0000004D 00000000
0000004E 00000000
0000004F 00000000
00000050 00000000
00000051 00000000
00000052 00000000
00000053 00000000
00000054 00000000
00000055 00000000
00000056 00000000
00000057 00000000
00000058 00000000
00000059 00000000
0000005A 00000000
0000005B 00000000
0000005C 00000000
0000005D 00000000
0000005E 00000000
0000005F 00000000
00000060 00000000
00000061 00000000
00000062 00000000
00000063 00000000
00000064 00000000
00000065 00000000
00000066 00000000
00000067 00000000
00000068 00000000
00000069 00000000
0000006A 00000000
0000006B 00000000
0000006C 00000000
0000006D 00000000
0000006E 00000000
0000006F 00000000
00000070 00000000
00000071 00000000
00000072 00000000
00000073 00000000
00000074 00000000
00000075 00000000
00000076 00000000
00000077 00000000
00000078 00000000
00000079 00000000
0000007A 00000000
0000007B 00000000
0000007C 00000000
0000007D 00000000
0000007E 00000000
0000007F 00000000
00000080 00000000
00000081 00000000
00000082 00000000
00000083 00000000
00000084 00000000
00000085 00000000
00000086 00000000
00000087 00000000
00000088 00000000
00000089 00000000
0000008A 00000000
0000008B 00000000
0000008C 00000000
0000008D 00000000
0000008E 00000000
0000008F 00000000
00000090 00000000
00000091 00000000
00000092 00000000
00000093 00000000
00000094 00000000
00000095 00000000
00000096 00000000
00000097 00000000
00000098 00000000
00000099 00000000
0000009A 00000000
0000009B 00000000
0000009C 00000000
0000009D 00000000
0000009E 00000000
0000009F 00000000
000000A0 00000000
000000A1 00000000
000000A2 00000000
000000A3 00000000
000000A4 00000000
000000A5 00000000
000000A6 00000000
000000A7 00000000
000000A8 00000000
000000A9 00000000
000000AA 00000000
000000AB 00000000
000000AC 00000000
000000AD 00000000
000000AE 00000000
000000AF 00000000
000000B0 00000000
000000B1 00000000
000000B2 00000000
000000B3 00000000
000000B4 00000000
000000B5 00000000
000000B6 00000000
000000B7 00000000
000000B8 00000000
000000B9 00000000
000000BA 00000000
000000BB 00000000
000000BC 00000000
000000BD 00000000
000000BE 00000000
000000BF 00000000
000000C0 00000000
000000C1 00000000
000000C2 00000000
000000C3 00000000
000000C4 00000000
000000C5 00000000
000000C6 00000000
000000C7 00000000
000000C8 00000000
000000C9 00000000
000000CA 00000000
000000CB 00000000
000000CC 00000000
000000CD 00000000
000000CE 00000000
000000CF 00000000
000000D0 00000000
000000D1 00000000
000000D2 00000000
000000D3 00000000
000000D4 00000000
000000D5 00000000
000000D6 00000000
000000D7 00000000
000000D8 00000000
000000D9 00000000
000000DA 00000000
000000DB 00000000
000000DC 00000000
000000DD 00000000
000000DE 00000000
000000DF 00000000
000000E0 00000000
000000E1 00000000
000000E2 00000000
000000E3 00000000
000000E4 00000000
000000E5 00000000
000000E6 00000000
000000E7 00000000
000000E8 00000000
000000E9 00000000
000000EA 00000000
000000EB 00000000
000000EC 00000000
000000ED 00000000
000000EE 00000000
000000EF 00000000
000000F0 00000000
000000F1 00000000
000000F2 00000000
000000F3 00000000
000000F4 00000000
000000F5 00000000
000000F6 00000000
000000F7 00000000
000000F8 00000000
000000F9 00000000
000000FA 00000000
000000FB 00000000
000000FC 00000000
000000FD 00000000
000000FE 00000000
000000FF 00000000

```

```

IFB TL21
DIA 0 DAC
LDA 2 ST12
LDA 1 SPADC
ADD 1 2
DIA 2 DAC
DIA 0 DAC
ENDC

IFB ATODE
DIA 0 DAC
LDA 3 SADC
LDA 1 SPADC
ADD 1 3
DIA 3 DAC
LDA 2 ATODE
LDA 1 SPADC
ADD 1 2
DIA 2 DAC
LDA 1 SPADC
DIA 1 DAC
LDA 1 SPADC
DIA 1 DAC
LDA 1 SPADC
DIA 1 DAC
DIA 3 DAC
DIA 0 DAC
ENDC

LDA 1 SPADC
LDA 1 SPADC

```

```

, READ AND SAVE THE STATUS OF THE DDDAC CONTRL
, LOAD THE SLOT ADDRESS OF THE SECOND TTL INPL
, OF=1, ID=1, CH=0
, SETUP TO LOCATE THE SECOND TTL INPUT DEVICE
, SELECT AND START THE SECOND TTL INPUT DEVICE
, RESTORE THE STATE OF THE DDDAC CONTROLLER

, START THE ADC DEVICE

, READ AND SAVE STATUS OF THE DDDAC CONTROLLER
, LOAD THE SLOT ADDRESS OF THE ADC DEVICE
, OF=1, ID=1, CH=0
, SETUP TO LOCATE THE ADC CLUSTER
, SELECT THE ADC CLUSTER
, NUMBER OF CONVERSIONS TO BE PERFORMED
, INT OVER=1, MUX BUS=1, TRIG=01, AUTO SCAN=1
, SET UP TO INDICATE THE NUMBER OF CONVERSIONS
, SPECIFY CONVERSIONS
, MUX NO=3, MUX CHAN=0
, SPECIFY MUX ADDRESS FOR DATA CHANNEL OPERATI
, ADDRESS WHERE CONVERTED DATA IS TO BE STORED
, SPECIFY MEMORY ADDRESS LOCATION AND START TO
, LOCATE THE ADC CLUSTER
, RESTORE THE STATE OF THE DDDAC CONTROLLER

, RETURN
, GET RETURN ADDRESS

```

34					. INPUT DATA
35	00374	177710	RTA	-16	
36	00375	000000	RADDR	0	. RETURN ADDR STORAGE
37	00276	100220	SPRBC	100220	. CP-1, ID-1, CH-0 IN SPECIFY ADDRESS AND CONTE
38					. EQUIVALENT TO 1,000,000,010,000,000
39	00277	000020	SPHX1	000020	. MUX NO-1, MUX CHAN-0 IN SPECIFY MUX ADDRESS
40					. EQUIVALENT TO 0,000,000,000,010,000
41	00100	000000	LOOFC	0	. LOOP COUNTER FOR BIT COUNTER
42	00301	100000	INTAL	0	. CHANNEL NUMBER OF THE DAC
43	00302	0-0000	DBDCN	0	. STATUS OF THE DBDC CONTROLLER
44	00303	000000	SPMNA	000000	. MUX NO-3, MUX CHAN-0 IN SPECIFY MUX ADDRESS
45					. EQUIVALENT TO 0,000,000,000,110,000
46	00304	100000	SPCON	100000	. INT OVER-1, MUX BUS-1, TRIG-01, AUTO SCANN-1, DCH-
47					. NEG-0, TRIG-0, CONVERSION COUNT-0 IN SPECIFY 01
48					. EQUIVALENT TO 1,101,110,000,000,000
49	00305	000000	SPMNA	000000	. MUX NO-2, MUX CHAN-0 IN SPECIFY MUX ADDRESS
50					. EQUIVALENT TO 0,000,000,000,100,000
51	00306	000017	SPRBC	000017	. VALUES 0,000,000,000,001,111 USED TO FIND THE
52					. SLOT ADDRESS OF THE INTERRUPTING DEVICE IN
53					. FOLLOWING ADDRESSE
54	00307	010000	FLDOR	010000	. FOR DATA OVERFLOW, 0,001,000,000,000,000
55	00310	010010	SPRBC	000010	. CP-0, ID-0, CH-1 IN SPECIFY ADDRESS AND CONTE
56					. EQUIVALENT TO 0,000,000,000,010,000
57	00311	010000	SPRBC	010000	. SETUP MODULE MASK TO MASK OUT ALL DBDC SLO
58					. EQUIVALENT TO 0,001,000,000,000,000
59					
60	00312	000000	RELAT	000000	. ADDR OF RELAY BIT STATUS TABLE
61	00313	000000	RELAT	000000	. NUMBER OF RELAYS IN SYSTEM
62					

0000	INTFLX			
01				
02			IFB DTORG	
03 00014 077777	DLA	ANPLG		ADDRESS OF DDC STORAGE TABLE
04 00015 000000		DTAS1		NUMBER OF CHANNELS FOR FIRST DDC DEVICE
05 00016 000000		DTAS2		NUMBER OF CHANNELS FOR SECOND DDC DEVICE
06		ENDC		
07				
08			IFB FLIO	
09 00017 077777	DTLO1			ADDRESS OF FIRST TTL OUTPUT DEVICE TABLE
10 00018 000000		FLIO		NUMBER OF OUTPUTS FOR FIRST TTL OUTPUT DEVICE
11				
12			IFB FLIO	
13 00019 077777	DTLO2			ADDRESS OF SECOND TTL OUTPUT DEVICE TABLE
14 00020 000000		FLIO		NUMBER OF OUTPUTS FOR SECOND TTL OUTPUT DEVICE
15				
16				
17				
18 00021 011111	INTFLX			ADDRESS OF INTERRUPT HANDLER
19 00022 011111	INTFLX			ADDRESS OF STATE SAVE AREA
20 00023 011111	INTFLX			ADDRESS OF INTERRUPT ROUTINE ADDRESS
21 00024 011111	INTFLX			ADDRESS OF INTERRUPT ROUTINE ADDRESS
22 00025 011111	INTFLX			ADDRESS OF INTERRUPT ROUTINE ADDRESS
23 00026 011111	INTFLX			ADDRESS OF INTERRUPT ROUTINE ADDRESS
24 00027 011111	INTFLX			ADDRESS OF INTERRUPT ROUTINE ADDRESS
25 00028 011111	INTFLX			ADDRESS OF INTERRUPT ROUTINE ADDRESS
26 00029 011111	INTFLX			ADDRESS OF INTERRUPT ROUTINE ADDRESS
27 00030 011111	INTFLX			ADDRESS OF INTERRUPT ROUTINE ADDRESS
28 00031 011111	INTFLX			ADDRESS OF INTERRUPT ROUTINE ADDRESS
29 00032 011111	INTFLX			ADDRESS OF INTERRUPT ROUTINE ADDRESS
30 00033 011111	INTFLX			ADDRESS OF INTERRUPT ROUTINE ADDRESS
31 00034 011111	INTFLX			ADDRESS OF INTERRUPT ROUTINE ADDRESS

11 000000 000000	LDN 1 8000	/CHECK IF CONTACT SENSE DEVICE WAS
12 000000 000000	SUB 1 2 800	/RESPONSIBLE FOR THE INTERRUPT
13 000000 000000	JMP OTHER	/JUMP TO CONTACT SENSE HANDLER
14 000000 000000	LDN 2 8111	/CHECK IF FIRST TTL INPUT DEVICE
15 000000 000000	SUB 1 2 800	/CAUSED THE INTERRUPT
16 000000 000000	JMP HLL11	/JUMP TO FIRST TTL INPUT HANDLER
17 000000 000000	LDN 2 8111	/CHECK IF THE SECOND TTL INPUT DEVICE
18 000000 000000	SUB 1 2 800	/CAUSED THE INTERRUPT
19 000000 000000	JMP HLL12	/JUMP TO SECOND TTL INPUT HANDLER
20 000000 000000	LDN 2 8000	/CHECK IF THE ADD DEVICE
21 000000 000000	SUB 1 2 800	/CAUSED THE INTERRUPT
22 000000 000000	JMP HLL11	/JUMP TO ADD INPUT HANDLER
23 000000 000000	DSN 00	/ERROR IF NONE OF THE ABOVE
24 000000 000000	HLL100	/PRINT ERROR MESSAGE
25 000000 000000	ADD 1 1	/SPECIFY RESCHEDULING
26 000000 000000	HLT	
27 000000 000000	IFB 0000	
28 000000 000000	SENSE	/ADDR OF CONTACT SENSE DISPATCH TABLE
29 000000 000000	LDN 1	/NUMBER OF CONTACT SENSES IN SYSTEM
30 000000 000000	0	/LAST SENSE PATTERN READ
31 000000 000000	0	/RETURN ADDR STORAGE
32 000000 000000	0	/COUNTER STORAGE
33 000000 000000	0	
34 000000 000000	0	
35 000000 000000	0	
36 000000 000000	0	
37 000000 000000	0	
38 000000 000000	0	
39 000000 000000	0	
40 000000 000000	0	
41 000000 000000	0	
42 000000 000000	0	
43 000000 000000	0	
44 000000 000000	0	
45 000000 000000	0	
46 000000 000000	0	
47 000000 000000	0	
48 000000 000000	0	
49 000000 000000	0	
50 000000 000000	0	
51 000000 000000	0	
52 000000 000000	0	
53 000000 000000	0	
54 000000 000000	0	
55 000000 000000	0	
56 000000 000000	0	
57 000000 000000	0	
58 000000 000000	0	
59 000000 000000	0	
60 000000 000000	0	
61 000000 000000	0	
62 000000 000000	0	
63 000000 000000	0	
64 000000 000000	0	
65 000000 000000	0	
66 000000 000000	0	
67 000000 000000	0	
68 000000 000000	0	
69 000000 000000	0	
70 000000 000000	0	
71 000000 000000	0	
72 000000 000000	0	
73 000000 000000	0	
74 000000 000000	0	
75 000000 000000	0	
76 000000 000000	0	
77 000000 000000	0	
78 000000 000000	0	
79 000000 000000	0	
80 000000 000000	0	
81 000000 000000	0	
82 000000 000000	0	
83 000000 000000	0	
84 000000 000000	0	
85 000000 000000	0	
86 000000 000000	0	
87 000000 000000	0	
88 000000 000000	0	
89 000000 000000	0	
90 000000 000000	0	
91 000000 000000	0	
92 000000 000000	0	
93 000000 000000	0	
94 000000 000000	0	
95 000000 000000	0	
96 000000 000000	0	
97 000000 000000	0	
98 000000 000000	0	
99 000000 000000	0	

0007 INTFL)		
01 00370 103000	ADD 1 2	,SENSE
02 0000071 071000	DCB 2 BAC	,MODULE
03 0000007 0-1400	DIB 0 BAC	,READ CONTACT SENSE INPUTS
04 00370 070710	LDA 1 CTRACT+1	
05		
06 00374 110000	COM 0 2	
07 00379 113404	AND 1 2 BIR	,CHANGE FROM 0 TO 1?
08 00374 100407	JMP +0	,YES
09 00374 110000	COM 1 2	,NO
10 00374 111000	COM 0 2 BIR	,CHANGE FROM 1 TO 0?
11 00374 000000	JMP +20	,NO-INTERRUPT NOT ON CONTACT SENSE
12 00374 110000	SUBR 1 1 BIR	,FORM 100000 FOR 0 TO 1 CHANGE
13 00374 111000	SUB 1 1	,FORM 0 FOR 1 TO 0 CHANGE
14 00374 000000	LDA 3 BIR	,GET BIR
15 00374 110000	ADD 3 1	,FORM LEFT PART OF MESSAGE WORD
16 00374 100000	LDA 3 CTRACT	,GET # CONTACT SENSES IN SYSTEM
17 00374 070000	STA 3 CTRACT+3	,INSTALL COUNTER
18 00374 110000	SUB 3 1	
19 00374 111000	NOVL 2 1 BIR	,IS BIT SET, STARTING AT BIT 0
20 00374 000000	JMP +0	,YES
21 00374 110000	NOVL 3 3	,NO-INC. POINTER
22 00374 110000	DCB CTRACT+3	,SCAN DONE?
23 00374 110000	JMP +0	,NO-CONTINUE
24 00374 000000	JMP +10	,YES-NO BITS CHANGED-INTERRUPT NO GOOD
25 00374 110000	SUB 3 CTRACT 1	,BIT FOUND-SAVE NEW SENSE PATTERN
26 00374 110000	NOVL 1 1	,FORM FINAL MESSAGE
27 00374 110000	LDA 0 CTRACT+1	,GET B.A. OF CONTACT SENSE DISPATCH TABLE

2A 00423 119000	ADD 0 3	/GET POINTER TO DISPATCH ADDR
2F 00423 021000	LDA 0 0 3	/GET DISPATCH ADDR
30 00424 077777	TXMT	/TRANSMIT MESSAGE TO DISPATCH TABLE
31 00425 007401	ORF +1	/RESTART THE CONTACT SENSE DEVICE
3700426 3 0000	LDA 3 3000	/LOAD THE SLOT ADDRESS OF THE CONTACT SENSE I
33000427 020000	LDA 1 3F000	/CF=1, ID=1, CH=0
34 00430 133000	ADD 1 2	/SETUP TO LOCATE THE CONTACT SENSE DEVICE
37000431 071100	DOAS 2 000	/SELECT AND START THE CONTACT SENSE DEVICE
35 00432 110000	LDA 0 00000	/LOAD THE STATE OF THE DGDAC CONTROLLER
37000433 001000	DAC 0 000	/RESTORE THE STATE OF THE DGDAC CONTROLLER
38 00434 037732	LDA 3 0TACT+2	/GET RETURN ADDR
39 00435 111000	ADD 1 1	/SPECIFY RESCHEDULING
40 00436 000100	OTEX	
41	/ENDC	
42		
43 00437 +11001	ADHAN	/ADC HANDLER
45 00440 020000	LDA 1 30000	/PLACE SUBSYSTEM IN
46 00441 000000	LDA 1 000	/CONTROL MODE
47 00442 000000	LDA 1 00000	/MASK OUT ALL MODULE
48 00443 000000	DAC 1 000	/LEVEL INTERRUPTS
49 00444 000000	LDA 2 3000	/LOCATE
4A 00445 000000	LDA 1 3F000	/THE
4B 00446 131000	ADD 1 2	/ADC
4C 00447 071000	DOAS 2 000	/MODULE
4D 00448 000000	DINC 1 000	/CHECK THE VALIDITY OF THE DATA FROM THE ADC
4E 00449 000000	LDA 0 00000	/CHECK THE DATA OVERRUN BIT
4F 00450 100000	AND 0 1 300	/GETS DATA OVERRUN BIT
50 00451 000000	DSRMO	/INDICATE ERROR
51 00452 000000	DSRMO	/ERROR - PRINT MESSAGE
52 00453 000000	LDA 0 00000	/LOAD THE STATE OF THE DGDAC CONTROLLER
53 00454 000000	DAC 0 000	/RESTORE THE STATE OF THE DGDAC CONTROLLER
54 00455 111000	ADD 1 1	/SPECIFY RESCHEDULING

```

0003 RTPLX
01 00407 000438 01EX
02
03
04
05
06
07
08
09 00408 007777 FTTL1 TTL11
10 00409 000000 TTL1
11 00410 000000 0
12 00411 000000 0
13 00412 004775 HTL11 STA 3 FTTL1+2
14 00413 004833 LDA 1 3ADCR
15 00414 005000 DCR 1 DDC
16 00415 004833 LDA 1 HRRAL
17 00416 004010 DDC 1 DDC
18 00417 004000 LDA 2 TTL1
19 00418 004801 LDA 1 3FADC
20 00419 004000 ADD 1 2
21 00420 004000 DCR 2 DDC
22 00421 004000 DCR 3 DDC
23 00422 004000 LDA 1 FTTL1
24 00423 000000 LDA 0 FTTL1+1
25 00424 000000 REG 0 0
26 00425 004775 STA 1 FTTL1+3
27 00426 004000 LDA 1 +1
28 00427 004000 RORL 3 0 3 AND
29 00428 004000 LDA 1 +0
30 00429 004000 STA 2 3 FTTL1+3
31 00430 004000 INC 1 1
32 00431 004000 INC 0 0 3CR
33 00432 004000 JNE +3
34 00433 004000 LDA 0 DDCR
35 00434 004000 DCR 0 DDC
36 00435 004000 LDA 3 FTTL1+2
37 00436 004000 ADD 1 1
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99

```

```

37
38
39      IFN TL21      , SECOND TTL INPUT HANDLER
40 00516 1077777  STLI  TTL12      , ADDRESS OF SECOND TTL INPUT TABLE
41 1100517 000000  TL21          , NUMBER OF TTL INPUTS FOR SECOND TTL INPUT DE
42 00520 000000  0              , RETURN ADDR STORAGE
43 00521 000000  0              , STORE CURRENT TABLE VALUE
44 00522 004776  STAL2  STA 3 STLI+2 , SAVE RETURN ADDR
45 00523 004000  LAR 1  SADDR      , PLACE SUBSYSTEM IN
46 00524 000000  DOR 1  DMC        , CONTROL MODE
47 00525 004000  LIR 1  MSHAL      , MASK OUT ALL MODULE
48 00526 004700  DOR 1  DMC        , LEVEL INTERRUPTS
49 00527 000000  LAR 2  ST12       , LOCATE
50 00528 004000  LAR 1  SFADD      , SECOND
51 00529 004000  ADD 1  2          , TTL INPUT
52 00530 004000  DOR 2  DMC        , MODULE
53 00531 004000  DIB 3  DMC        , READ SECOND TTL INPUTS INTO ACS
54 00532 004000  LAR 1  STLI      , GET ADDR OF SECOND TTL INPUT TABLE
55 00533 004000  LAR 0  STLI+1     , GET NUMBER OF SECOND TTL INPUTS IN SYSTEM
56 00534 004000  DOR 0  0         , MAKE LOOP COUNTER
57 00535 004000  STA 1  STLI+3     , LOAD CURRENT TABLE POSITION INTO AC1
58 00536 004000  LAR 2  +1        , ASSUME BIT IS A ONE
59 00537 004000  MOVE 3  0 3  SMC  , SHIFT BIT INTO CARRY, EXAMINE CARRY
60 00538 004000  1 1100

```

```

0005 MTLX
01 00047 030000 LDA 2 40 ; IF BIT IS A ZERO
02 00048 030000 STA 2 @ STTL1+3 ; LOAD VALUE INTO SECOND TTL INPUT TABLE
03 00049 030000 INC 1 1 ; INCREMENT TABLE POSITION
04 00050 030000 INC 0 0 BIR ; CHECK IF ALL INPUTS HAVE BEEN LOADED
05 00051 030000 JMP -7 ; IF NOT CONTINUE
06 00052 030000 LDA 0 DSDCM ; LOAD THE STATE OF THE DSDAC CONTROLLER
07 00053 030000 DDC 0 DAC ; RESTORE THE STATE OF THE DSDAC CONTROLLER
08 00054 030000 ADD 1 1 ; SPECIFY RESCHEDULING
09 00055 030000 UIEX
10 ENDC
11
12 DSDCM EQU 0 ; STATE SAVE AREA
13 END ; END OF MTLX

```

0000

0010 HTFLY

ADHAN	000437	3/19	7/44						
ANALG	000514	3/10							
ATDDE	000530	3/10	3/13						
BITI	000540	3/31	7/14						
CNDAC	000501	2/53	3/04	3/12	3/25	3/37	3/45	5/39	
ENTCT	000500	1/49	3/14	3/43					
CTACT	000531	3/46	3/33	7/04	7/16	7/17	7/22	7/23	7/27
		7/35							
CTFAM	000531	3/30	3/33						
DOP	000514	2/57	3/35	3/29	3/32	6/05			
DAC	000500	1/42	1/43	1/50	1/38	1/57	2/04	2/08	2/12
		2/14	2/40	2/44	2/45	2/46	2/50	3/02	3/10
		3/15	3/22	3/35	3/43	3/51	4/14	4/18	4/19
		4/20	4/31	4/38	4/47	4/48	4/52	4/58	4/57
		5/02	5/08	5/07	5/11	5/15	5/19	5/21	5/23
		5/24	5/25	5/26	5/24	5/33	5/37	7/02	7/03
		7/33	7/37	7/43	7/47	7/51	7/52	7/58	8/12
		8/14	8/15	8/17	8/22	8/46	8/48	8/52	8/53
		8/57							
DOVA	000507	3/31	3/33						
DOVAM	000507	3/22							
DOVAF	000500	1/37							
DOVAL	000500	2/31	3/1	3/11	3/30	3/40	6/23	7/34	7/37
		8/31	8/34						

DATA1	000000	8/18	7/12					
DATA2	000000	8/40	7/35					
DATA3	000000	2/41	8/04					
DATA4	000000	3/21	8/05					
DATA5	000000	3/03						
ERROR	000000	1/44						
FTTLL	000110	8/08	8/10	8/20	8/21	8/23	8/27	8/33
FTTLL	000317	3/36	3/57	4/07	3/09			
GAINI	000000	2/03						
GAINI	000000	2/13						
HTLL1	000414	8/31	8/10					
HTLL2	000323	3/36	8/44					
LOPFC	000100	3/03	3/14	3/36	3/47	3/38		
NEG10	000000	8/41	7/36					
NEHAI	000311	3/34	8/36	7/48	8/16	3/47		
HTPLX	000071	2/19						
HL	000174	2/34	8/08	4/36	3/32			
PAULC	000321	1/47	8/19					
FTLLR	000336	8/21	8/23					
RODA	000170	1/37	2/17	2/17	8/26	3/33		
RELAY	000312	3/57						
RELAY	000000	2/31	8/36	3/36				
RS	000417	2/38	3/24	2/38	3/39			
SAFE	000000	3/12	8/17	1/18				
SAFE1	000310	3/32	8/34	7/44	8/11	8/43		
SAFE2	000101	3/48	8/18					
SAFE3	000000	8/38						
SAFE4	000000	3/27						
SAFE5	000000	1/32	3/24	8/36	7/32			
SAFE6	000000	3/32						
SAFE7	000000	3/14						
SAFE8	000000	3/14						
SAFE9	000000	3/14						
SAFE10	000000	3/14						
SAFE11	000000	3/14						
SAFE12	000000	3/14						
SAFE13	000000	3/14						
SAFE14	000000	3/14						
SAFE15	000000	3/14						
SAFE16	000000	3/14						
SAFE17	000000	3/14						
SAFE18	000000	3/14						
SAFE19	000000	3/14						
SAFE20	000000	3/14						
SAFE21	000000	3/14						
SAFE22	000000	3/14						
SAFE23	000000	3/14						
SAFE24	000000	3/14						
SAFE25	000000	3/14						
SAFE26	000000	3/14						
SAFE27	000000	3/14						
SAFE28	000000	3/14						
SAFE29	000000	3/14						
SAFE30	000000	3/14						
SAFE31	000000	3/14						
SAFE32	000000	3/14						
SAFE33	000000	3/14						
SAFE34	000000	3/14						
SAFE35	000000	3/14						
SAFE36	000000	3/14						
SAFE37	000000	3/14						
SAFE38	000000	3/14						
SAFE39	000000	3/14						
SAFE40	000000	3/14						
SAFE41	000000	3/14						
SAFE42	000000	3/14						
SAFE43	000000	3/14						
SAFE44	000000	3/14						
SAFE45	000000	3/14						
SAFE46	000000	3/14						
SAFE47	000000	3/14						
SAFE48	000000	3/14						
SAFE49	000000	3/14						
SAFE50	000000	3/14						
SAFE51	000000	3/14						
SAFE52	000000	3/14						
SAFE53	000000	3/14						
SAFE54	000000	3/14						
SAFE55	000000	3/14						
SAFE56	000000	3/14						
SAFE57	000000	3/14						
SAFE58	000000	3/14						
SAFE59	000000	3/14						
SAFE60	000000	3/14						
SAFE61	000000	3/14						
SAFE62	000000	3/14						
SAFE63	000000	3/14						
SAFE64	000000	3/14						
SAFE65	000000	3/14						
SAFE66	000000	3/14						
SAFE67	000000	3/14						
SAFE68	000000	3/14						
SAFE69	000000	3/14						
SAFE70	000000	3/14						
SAFE71	000000	3/14						
SAFE72	000000	3/14						
SAFE73	000000	3/14						
SAFE74	000000	3/14						
SAFE75	000000	3/14						
SAFE76	000000	3/14						
SAFE77	000000	3/14						
SAFE78	000000	3/14						
SAFE79	000000	3/14						
SAFE80	000000	3/14						
SAFE81	000000	3/14						
SAFE82	000000	3/14						
SAFE83	000000	3/14						
SAFE84	000000	3/14						
SAFE85	000000	3/14						
SAFE86	000000	3/14						
SAFE87	000000	3/14						
SAFE88	000000	3/14						
SAFE89	000000	3/14						
SAFE90	000000	3/14						
SAFE91	000000	3/14						
SAFE92	000000	3/14						
SAFE93	000000	3/14						
SAFE94	000000	3/14						
SAFE95	000000	3/14						
SAFE96	000000	3/14						
SAFE97	000000	3/14						
SAFE98	000000	3/14						
SAFE99	000000	3/14						
SAFE100	000000	3/14						

0011	RTFLX						
SPCON	0000047	5/17	5/15				
SPBAC	0000000	7/33					
SPHX1	0000777	5/38					
SPHX2	0000037	2/11	5/48				
SPHX3	0000037	2/03	5/20	5/41			
SPLY	0000000	2/41					
ST11	0000000	4/53	5/31	5/15			
ST12	0000000	5/03	5/34	5/49			
ST01	0000000	4/10					
ST02	0000000	4/43					
STTL1	0000187	5/40	5/44	5/34	5/35	5/37	5/02
STTL2	0000217	4/25	4/26	4/33	5/14		
SVH1	0000000	2/02					
SVH2	0000000	2/10					
TL11	0000000	4/31	5/05	5/07			
TL12	0000000	5/03	5/10				
TL11	0000000	5/01	5/04	5/41			
TL12	0000000	4/23	5/13	5/10			
TL13	0000000	3/54					
TTL11	0000107	5/03					
TTL12	0000117	5/40					
TTL01	0000117	5/05					
TTL02	0000217	5/14					
UAT	0000107	7/30					
UCEX	0000107	5/24					
UDX	0000107	5/43	7/10	5/01	5/33	5/04	

Figure 10
Additions to OPCOM Messages

Source: <http://www.irs.gov/efile/efilefaq.html>.

1990 1991 1992 1993 1994 1995 1996 1997 1998 1999 2000 2001 2002 2003 2004 2005 2006 2007 2008 2009 2010 2011 2012 2013 2014 2015 2016 2017 2018 2019 2020 2021 2022 2023 2024 2025 2026 2027 2028 2029 2030 2031 2032 2033 2034 2035 2036 2037 2038 2039 2040 2041 2042 2043 2044 2045 2046 2047 2048 2049 2050 2051 2052 2053 2054 2055 2056 2057 2058 2059 2060 2061 2062 2063 2064 2065 2066 2067 2068 2069 2070 2071 2072 2073 2074 2075 2076 2077 2078 2079 2080 2081 2082 2083 2084 2085 2086 2087 2088 2089 2090 2091 2092 2093 2094 2095 2096 2097 2098 2099 2100 2101 2102 2103 2104 2105 2106 2107 2108 2109 2110 2111 2112 2113 2114 2115 2116 2117 2118 2119 2120 2121 2122 2123 2124 2125 2126 2127 2128 2129 2130 2131 2132 2133 2134 2135 2136 2137 2138 2139 2140 2141 2142 2143 2144 2145 2146 2147 2148 2149 2150 2151 2152 2153 2154 2155 2156 2157 2158 2159 2160 2161 2162 2163 2164 2165 2166 2167 2168 2169 2170 2171 2172 2173 2174 2175 2176 2177 2178 2179 2180 2181 2182 2183 2184 2185 2186 2187 2188 2189 2190 2191 2192 2193 2194 2195 2196 2197 2198 2199 2200 2201 2202 2203 2204 2205 2206 2207 2208 2209 2210 2211 2212 2213 2214 2215 2216 2217 2218 2219 2220 2221 2222 2223 2224 2225 2226 2227 2228 2229 2230 2231 2232 2233 2234 2235 2236 2237 2238 2239 2240 2241 2242 2243 2244 2245 2246 2247 2248 2249 2250 2251 2252 2253 2254 2255 2256 2257 2258 2259 2260 2261 2262 2263 2264 2265 2266 2267 2268 2269 2270 2271 2272 2273 2274 2275 2276 2277 2278 2279 2280 2281 2282 2283 2284 2285 2286 2287 2288 2289 2290 2291 2292 2293 2294 2295 2296 2297 2298 2299 2300 2301 2302 2303 2304 2305 2306 2307 2308 2309 2310 2311 2312 2313 2314 2315 2316 2317 2318 2319 2320 2321 2322 2323 2324 2325 2326 2327 2328 2329 2330 2331 2332 2333 2334 2335 2336 2337 2338 2339 2340 2341 2342 2343 2344 2345 2346 2347 2348 2349 2350 2351 2352 2353 2354 2355 2356 2357 2358 2359 2360 2361 2362 2363 2364 2365 2366 2367 2368 2369 2370 2371 2372 2373 2374 2375 2376 2377 2378 2379 2380 2381 2382 2383 2384 2385 2386 2387 2388 2389 2390 2391 2392 2393 2394 2395 2396 2397 2398 2399 2400 2401 2402 2403 2404 2405 2406 2407 2408 2409 2410 2411 2412 2413 2414 2415 2416 2417 2418 2419 2420 2421 2422 2423 2424 2425 2426 2427 2428 2429 2430 2431 2432 2433 2434 2435 2436 2437 2438 2439 2440 2441 2442 2443 2444 2445 2446 2447 2448 2449 2450 2451 2452 2453 2454 2455 2456 2457 2458 2459 2460 2461 2462 2463 2464 2465 2466 2467 2468 2469 2470 2471 2472 2473 2474 2475 2476 2477 2478 2479 2480 2481 2482 2483 2484 2485 2486 2487 2488 2489 2490 2491 2492 2493 2494 2495 2496 2497 2498 2499 2500 2501 2502 2503 2504 2505 2506 2507 2508 2509 2510 2511 2512 2513 2514 2515 2516 2517 2518 2519 2520 2521 2522 2523 2524 2525 2526 2527 2528 2529 2530 2531 2532 2533 2534 2535 2536 2537 2538 2539 2540 2541 2542 2543 2544 2545 2546 2547 2548 2549 2550 2551 2552 2553 2554 2555 2556 2557 2558 2559 2560 2561 2562 2563 2564 2565 2566 2567 2568 2569 2570 2571 2572 2573 2574 2575 2576 2577 2578 2579 2580 2581 2582 2583 2584 2585 2586 2587 2588 2589 2590 2591 2592 2593 2594 2595 2596 2597 2598 2599 2600 2601 2602 2603 2604 2605 2606 2607 2608 2609 2610 2611 2612 2613 2614 2615 2616 2617 2618 2619 2620 2621 2622 2623 2624 2625 2626 2627 2628 2629 2630 2631 2632 2633 2634 2635 2636 2637 2638 2639 2640 2641 2642 2643 2644 2645 2646 2647 2648 2649 2650 2651 2652 2653 2654 2655 2656 2657 2658 2659 2660 2661 2662 2663 2664 2665 2666 2667 2668 2669 2670 2671 2672 2673 2674 2675 2676 2677 2678 2679 2680 2681 2682 2683 2684 2685 2686 2687 2688 2689 2690 2691 2692 2693 2694 2695 2696 2697 2698 2699 2700 2701 2702 2703 2704 2705 2706 2707 2708 2709 2710 2711 2712 2713 2714 2715 2716 2717 2718 2719 2720 2721 2722 2723 2724 2725 2726 2727 2728 2729 2730 2731 2732 2733 2734 2735 2736 2737 2738 2739 2740 2741 2742 2743 2744 2745 2746 2747 2748 2749 2750 2751 2752 2753 2754 2755 2756 2757 2758 2759 2760 2761 2762 2763 2764 2765 2766 2767 2768 2769 2770 2771 2772 2773 2774 2775 2776 2777 2778 2779 2780 2781 2782 2783 2784 2785 2786 2787 2788 2789 2790 2791 2792 2793 2794 2795 2796 2797 2798 2799 2800 2801 2802 2803 2804 2805 2806 2807 2808

— 100 —

0120 OUTPUT BUFFER ERROR
 0121 LIST ERROR, ENTRY #
 0122 SOURCE FILENAME
 0123 NO COPY TO TTY DEVICE
 0124 CRASH IN THE "KILL" CYCLE
 0125 NO ANALOG OUTPUTS
 0126 0127 FIRST DATA OUTPUT DATA STORAGE NOT DEFINED 0150 0120
 0128 0129 INTERRUPTING DEVICES NOT DECLARED 0150 0120
 0130 0131 OVERFLOW ERROR - NO INPUTS 0150 0120
 0132 0133 SECOND DATA OUTPUT DATA STORAGE NOT DEFINED 0150 0120
 0134 0135 FIRST TTL INPUT DATA STORAGE NOT DEFINED 0150 0120
 0136 0137 SECOND TTL INPUT DATA STORAGE NOT DEFINED 0150 0120
 0138 0139 FIRST TTL OUTPUT DATA STORAGE NOT DEFINED 0150 0120
 0140 0141 SECOND TTL OUTPUT DATA STORAGE NOT DEFINED 0150 0120
 0142 0143 ERROR-ROLLING CODE-INTERAFT CAUSED BY UNDEFINED DEVICE 0150 0120
 0144 SET HYDROGEN LOG
 0145 HAVE BEEN LOG
 0146 HYDROGEN FLOW CONTROL
 0147 SET BY TIME LOG
 0148 HYDROGEN FLOW CONTROL
 0149 0150 HYDROGEN FLOW CONTROL
 0151 0152 HYDROGEN FLOW CONTROL
 0153 0154 TEMPERATURE SET POINT
 0155 0156 FUNCTION THREE TO SET REMAINING FLOWRATES
 0157 0158 FOR OVERFLOW INITIATED
 0159 0160 ALL FLOWS OFF, COOLING ON, FEED VENTING ON
 0161 0162 TEMPERATURE FLOWRATES LOG
 0163 0164 TEMPERATURE FLOWRATES LOG

6-

BIBLIOGRAPHY

- 1- Harrison, Thomas J. Handbook of Industrial Control Computers.
New York: John Wiley and Sons Inc., 1972.
- 2- Tremblay, Pierre. "Direct Digital Control of a Butane
Hydrogenolysis Chemical Reactor". M. ENG. Thesis,
McMaster University, 1973.
- 3- Data General Corporation. DGDAC and Process Controls
Programmer's Reference Manual, 1977
- 4- Smith, Cecil L. Digital Computer Process Control. Scranton,
Pennsylvania: Intext Educational Publishers, 1972.
- 5- Tremblay, Pierre. "Generalized Operating System Executive",
Internal Report, SOC Group, McMaster University,
(March 1975).
- 6- Carpenter, B.E. "A Computer Scientist's View of Process
Control", Massey University Computer Unit, Report No.
21 (June 1975).
- 7- Smith, C.L. "Fill-In-The-Forms Computer Languages For Process
Control", Chemical Engineering, (March 3, 1975).
- 8- Shave, John. "Process Control Software", Control and Instrument-
ation, Vol. VII, No. 10 (November 1975), 30.
- 9- Smythe, Clare. "Integrated Control of Paper Machine", Control
and Instrumentation, Vol. VI, No. 1 (November 1975), 30.
- 10- Gertler, Janos and Sedlak, Jan. "Software For Process Control -
A Survey", Automatica, Vol. XI, Pergamon Press, 1975
(613-625).
- 11- Data General Corporation. User Device Driver Implementation
In The Real Time Operating System, Manual No. 017-
000006-00, March, 1974.
- 12- Data General Corporation. Extended Assembler, Manual No. 093-
000040-01, May 1974.
- 13- Data General Corporation. How To Use The Nova Computers,
1971.